



USER'S MANUAL

Shoe & Boot Dryer ES10085US

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

INSTRUCTION MANUAL **SAVE THIS MANUAL FOR FUTURE REFERENCE** **GENERAL SAFETY RULES**



WARNING ! READ AND UNDERSTAND ALL INSTRUCTIONS

Failure to follow all instructions listed may result in electric shock, fire and / or serious personal injury

AREA OF USE:

- *Keep surrounding area clean and well lit. Cluttered areas may cause accidents.*
- *Do NOT operate in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.*
- *Household use Only.*

ELECTRICAL SAFETY:

- Do NOT override the timer switch.
- Do NOT operate in standing water .
- Do NOT overload with garments.
- Do NOT cut-off or restrict air circulation.
- *Do NOT expose to rain or snow.*
- *Use of attachments not recommended may result in a risk of fire, electric shock, or injury to persons.*
- To reduce risk of damage to electric plug and cord , pull by plug rather than cord when disconnecting unit .
- Make sure cord is positioned so that it will not be stepped on , tripped over or otherwise subjected to damage or stress.
- *Two-wire cord can be used with 2-wire extension cord. Only round jacketed extension cord should be used and we recommend that they be listed by Underwriters Laboratories (U.L). If the extension cord is to be used for indoor use. The letters "W" or "WA" on the cord jacket indicate that the cord is suitable for outdoor use.*
- An extension cord must have adequate wire size (AWG or American Wire Gauge)for safety and to prevent loss of power and overheating. The smaller the gauge number of the wire, the greater the capacity of the cable; that is, 16 gauge has more capacity than 18 gauge. When using more than 1 extension to make up the total length, be sure each extension contains at least the minimum wire size.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock ,this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

▲ ANNOUNCEMENT :

- *The boot dryer generates a gentle breeze,a light wind that evenly dries garments that will not damage your boots.* It is not a hair dryer and is not designed to force a powerful current of air through garments.
- *The boot dryer only heats to a gentle temperature.It is not designed to generate high heat as this would damage footwear.*

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS:

1. Plug the *boot dryer* into any standard 120 Volt 60 Hz electrical outlet
2. Unfold the 4 anti-slip pads under the bottom base, and pull up the upper tubes when drying boots up to 16" tall.The *boot dryer* dries boots and gloves together or 2 pair of long boots and other types of shoes simultaneously by pulling up the two upper stretchable tubes directly. Push the two sides' locking buttons simultaneously and slide down the upper tubes if you wish to faster drying. *Front two smaller tubes are specially designed for drying kids shoes or boots or socks or gloves.*
3. The upper tubes with anti-being pulled off system will prevent the tubes falling put when pulling off the long boots after drying.
4. Carefully slide footwear onto drying tubes or drying *nozzles*, *being careful* not to restrict air flow at the bottom or block air flow into the lower assembly.
5. Select the heat or no heat setting by pressing the rocker switch at the top of housing
6. Turn timer knob clockwise to the 180 minute mark to initially activate the timer switch (please note as this is very important), then turn knob counter-clockwise back to desired drying time.timer will auto off.
7. *When turn on the UV/Ozone switch to sterilization, please do make sure open all the windows or doors for good air circulation to avoid any potential harm to your lung healthy. DONOT USE THE STERILIZATION FUNCTION IN A CLOSED ROOM/CONFINED SPACE OR BED ROOM, KEEP IT AWAY FROM THE KIDS OR DISABLE PEOPLES!*

Optional function:

If your machine is made with UV/Ozone sterilization function,Please switch ON the independent switch besides the Timer dial to turn ON the UV/OZONE generator to produce the UV/OZONE for sanitizing your shoes.if donot want UV/OZONE ,just turn OFF the switch independently for drying function only.

CAUTION: PLEASE DONOT CLOSE TO THE MACHINE AND BREATH OVER 15MINS IF TURN ON THESTERILIZATION FUNCTION TO AVOID POTENITAL HARM TO YOUR LUNGS.PLEASE KEEP AWAY FROM THE MACHINE AND OPEN THE WINDOW OR DOOR FOR VENTILATION DURING OR AFTER STERILIZATION.

HELPFUL TIPS:

1. *The boot dryer creates a gentle breeze to dry garments gently, but it is not a hair dryer that will not create a strong wind.*
2. When placing gloves, mittens or children's boots and shoes onto the drying tubes or drying nozzles, be sure not to pinch air circulation
3. Footwear should be dried after every use to help prevent bacteria and fungus growth, the primary cause of odor.
4. Smaller footwear and garments will dry quicker than larger items.
5. Your energy efficient *boot dryer* heats to a gentle temperature of around 122 °F/50 °C based on room temperature of 25 °C and uses "Forced Air" technology quietly and quickly dries wet garments, but it does not generate a forceful air stream that might possibly damage or deform the shoes.
6. At first you may suspect the unit is not operating properly. We recommend you place the back of your hand near the drying nozzles so you will better feel the gently warmed air stream and to experience the heat, place footwear and garments onto the drying nozzles for a period of *30 minutes*, then touch inside the garment to feel the gentle heat.
7. Use shoe stretcher or front two smaller tubes to dry Ski Boots or gloves or socks.
8. The upper tubes stretched will be little shaking which is normal and strong enough to hold any boots without any problem.

OPERATION TIME:

- Timer must turn past 1 hour to activate. For drying time less than 1 hour, turn timer knob clockwise past 1 hour mark and counter clockwise back to desired time.
- 1 to 3 hours, but please avoid over-drying.
- Drying time varies depending upon extent of moisture as well as temperature and humidity
- We recommend a minimum of 1 hour every time your shoes or boots are used.
- While in operation, the unit although relatively quiet, produces minimal noise. This is a normal condition and does not indicate a problem.

MAINTENANCE:

Use only mild soap and a damp cloth to clean the dryer. Never let any liquid get inside the motor.

You can coil the cord to its specially designed cord coil system back of the main body and slide down all upper tubes for easier storage.

IMPORTANT:

To assure product SAFETY and RELIABILITY, repairs and maintenance (other than those listed in this manual) should be performed by qualified service organizations, always using identical replacement parts.