

COSTWAY®





THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com













Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

♠ Please read all instructions carefully.

🔨 Retain instructions for future reference.

♠ Seperate and count all parts and hardware.

riangle Read through each step carefully and follow the proper order.

We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

⚠ Always place the product on a flat, steady and stable surface.

⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Safety and Assembly Instructions

IMPORTANT

READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS, KEEP FOR FUTRUE REFERENCE



WARNING! CHOKING HAZARD-SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS

WARNING! DO NOT USE WITHOUT ADULT SUPERBISION! WARNING! ADULT ASSEMBLING REUIRED!

ESSENTIAL INFORMATION

- Recommended for children 3+ years
- Do not leave child unattended while in use
- CAUTION: Use only under adult supervision
- Good safety practices should be followed at all times
- Read all instruction before using this product.

Intended solely for family and domestic use, not for a commercial playground or daycare. Two adults needed for assembly.

Hanging hardware not included. Ideally, the swing body should be hung over

grass, sand, wood chips, or other soft surfaces. Under no circumstances should it be hung over concrete, asphalt, or other hard surfaces. Distance from ground should not exceed 40cm; the maximum fall height should not be more than 46cm, Two S hooks are attached to the rope to allow for adjustment of the rope length.

Please be sure to examine the ropes regularly to check for wear. Rope will, in time, degrade. If the color of the rope has become pale, frays easily, or gives off a powdery material when rubbed between the fingers, we recommend you replace the rope.

Equipment should be hung in such a way that a distance of at least 2m is clear on either side. Can be hung on an A-frame or swing set or on a tree limb of a diameter of at least 25cm.

WARNING! Small parts for assembly by an adult.

Tools Required (included in the packaging)



Swing Assembling



 Swing arrives in 4pcs tubes, and 2 hanging ropes, a swinging body for assembly.



 Put the swinging body on the floor, and put the 4 Velcro covers in the direction of black mat.



3. Insert the arched tube with foam into the sleeve firstly.



4. Insert the straight tube into the sleeve; connect two tubes by small socket to big socket. Repeat it until all the tubes connected.



 Repeat step 3 and 4 until all the tubes are inserted.
Please note that the last tube inserted should be the arched one.



6. Connect the body as an oval platform



7. Put the screw bolt through the Velcro cover.



8. Insert the screw bolt into the holes and secured by washer and nut.



9. Use wrench to tighten the nut.



10. Cover the Velcro back.



11. Top looking and appearance



12. Assembly finished, and it is ready to swing

Ensuring Safety of the Swing

Clearance distance should be 4m around the swing.

A fall onto a hard surface can result in serious injury to the equipment user.

Do not use the equipment until properly installed.

This swing is not to be used in any other manner other than its intended use.

Adult supervision is required.

Adults should verify that the hanging ropes are secured and cannot be looped back on the swing. It is important for adults to instruct children to:

- Dress appropriately while using the swing (avoid ponchos, scarves, and other loose-fitting clothing that is potentially hazardous)
- Sit in the center of the swing with full weight on the seat if swinging alone
- Avoid swinging empty seats
- Do not lean heavily on the sides of tent
- Never lean on the gate of tent

It is important for adults to instruct children **NOT to**

- Walk close to, in front of, behind, or between moving items
- Twist ropes or loop them over the top support bar since such action may reduce the strength of the rope
- Get off the sing while it is in motion
- Climb on the swing when it is wet.
- Attach additional items to the swing that might cause a strangulation hazard.
- Wear a bicycle or sport helmet while on the swing.

Maintaining the Swing

At the beginning of the each play season, adults should:

- Tighten all hardware.
- Tighten all the buckles of tent
- Check all protective coverings on pipes, edges, and corners, Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seat, ropes for wear, rust, or other deterioration, Replace as needed. The hardware used for this swing (binding post, screw, S hook, lock washer, flat washer, and metal ring) can be found at local hardware store.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be guite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana. California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

