
COSTWAY



USER'S MANUAL 25" Freestanding Electric Fireplace Stove

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway









FP10059US



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

- ♠ Please read all instructions carefully.
- A Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- riangle Read through each step carefully and follow the proper order.
- Me recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Table of Contents

Warnings & Precautions

Technical Specification

Package Contents

Installation guide

Users Instruction

Care and Maintenance

When using electrical appliances, basic safety precautions should always be followed including the following:

READ ALL INSTRUCTIONS BEFORE USE AND SAVE THESE INSTRUCTIONS

- 1. Read all instructions before using this heater.
- 2. Do not use this heater outdoors.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate the heater where it may fall into a bathtub or other water container.
- 4. Do not run the power cord under carpeting. Do not cover the power cord with throw rugs, runners, or the like. Arrange the power cord away from traffic areas and where it will not be tripped over.
- 5. To disconnect the heater, turn controls to off, then remove the plug from the outlet.
- Connect to properly grounded outlet only. Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or reloadable power tap (outlet/power strip).
- To prevent a possible fire, do not block operate the firebox on soft surfaces, like a bed, where openings may become blocked.
- There is a thermostat limiter inside the heater. When the inner temperature overheat or abnormal heating occurs, the thermostat protective device cuts off the power supply to avoid fireplace from damaged or risk of fire.
- Use the heater only as described in the manual. Any other use not recommended by the manufacturer may cause fire, electrical shock, or injury to persons.
- 10. WARNING: Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.

⚠ WARNING: There is no user serviceable parts inside fireplace/heater. If the unit appears to malfunction, turn the unit off and unplug from the wall immediately and contact Customer Service.

⚠ WARNING: This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible material, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3ft (0.9m) from the front of the heater and keep them away from the side or rear.

⚠ WARNING: Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped, or damaged in any manner. Return the heater to an authorized service facility for examination, electrical or mechanical adjustment, or repair.

⚠ WARNING: Do not insert or allow foreign objects to enter any ventiliation or exhaust openings as this may cause an electric shock or fire, or damage to the heater.


⚠ CAUTION: While the heater is in use, the top center of the fireplace can get hot to the touch, and may cause serious injury or burns. Always supervise small children around the fireplace/heater. Do not place any cloth or decorations over the heater outlet or fireplace, or otherwise obstruct the heater outlet of the fireplace, as this may cause a fire and serious injury.



Specifications

Model Number	SF507-25B
Dimensions (W x D x H)	25"x15"x28.3"
Net Weight	35.27 lbs
Gross Weight	42.55 lbs
Power Rating	1400 W
Voltage	120 V
Frequency	60 Hz

Package Contents




Main Unit



Screw x8



Installation Guide



Assembly Instruction

- 1. Take out the unit from the box and layout all the spare parts for easy assembly. Make sure all small items are not left in the packaging materials.
- 2. Lay the unit upside down.
- 3. Attach the leg to the unit by aligning the tabs on the leg to the slot on the unit.
- 4. Secure the leg on the unit by tighten 2 screws into the pre-drilled hole.
- 5. Repeat the above steps for the remaining legs.

Placing the Unit

Place the unit on smooth level surface.

Keep combustible objects at least 3ft away from the unit.

Allow at least 4" of clearance space around the side of the unit.

Place the unit to a location that is accessible to grounded power socket.

NOTE:

This unit is intended for indoor use only.

Do not push, pull, or drag the unit to prevent damage to the legs or the unit.




Installation Guide

Polarized Plug

This product is equipped with a polarized plug (one blade is wider than another). This plug will only fit into the outlet in one way to reduce the risk of electric shock.

This unit comes standard with a 6ft (1.8m) long, three wired cord. Always plug the unit into a wall outlet. An extension or relocate tab should never be used.

<u>A</u> **CAUTION! WARNING:** DO NOT modify the plug provided with the product if it does not fit the outlet. Have a proper outlet installed by a qualified electrician.




User Instruction

Before use

Check that the air intake and exhaust is not covered or obstructed in anyway.

Plug the unit to a grounded power socket.



Power ON / OFF

Flip the power switch to "ON" position to power on the unit. Flip the power switch to "OFF" position to power off the unit.

↑ CAUTION! WARNING: DO NOT unplug the unit when it is still "ON"

Heater

Toggle the Temperature switch to turn on the heater. Turn the temperature knob to select the desired temperature.

Flame Effect

The flame effect will be visible through the front window after turning the power switch to "ON" position.

Temperature Limiting Feature

This unit will automatically shut off if the heater reaches an unsafe temperature. To reset, Toggle the power switch to "off" position, unplug the socket and wait for at least 5 minutes before plugging the unit to a grounded power outlet and turning on the unit.

User Instruction

Care and Maintenance

Cleaning the unit:

Always turn off the heater and unplug the unit from power outlet before cleaning.

Use a vacuum cleaner or duster to remove dust and dirt from the heater and vent areas.

Use a damp soft cloth to clean the surface and buff with a dry cloth.

Do not use abrasive cleansers, liquid sprays or any cleaner that could scratch the surface.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.





