COSTWAY

SHOP EASY. SAVE MONEY.



USER'S MANUAL

Storage Cabinet

HW57075

PRODUCT ASSEMBLY

Hardwares List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
A	Cam-Bolt		28 pcs	D	Screw		30 pcs
B	Cam-lock		28 pcs	E	Screw	4*30mm	3 pcs
C	Wood Dowel		35 pcs	F	Screw	4*40mm	6 pcs

Parts List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Top Panel		1 pc	8	Front Panel		1 pc
2	Middle Shelf		1 pc	9	Bottom Connect Bar		1 pc
3	Bottom Panel		1 pc	10	Middle Connect Bar		1 pc
4	Left Side Panel		1 pc	11	Upper Back Panel		1 pc
5	Upper Divide Panel		1 pc	12	Lower Back Panel		1 pc
6	Right Side Panel		1 pc	13	Top Connect Bar		1 pc
7	Lower Divide Panel		1 pc				

Part List Assembly Overview



Step 1



a) Attach Upper Divide Panel (5) to Middle Shelf (2) by using Wood Dowel (C) and Screw (F) as shown. Do not Overtighten.
b) Attach Middle Connect Bar (10) to Middle Shelf (2) by using Wood Dowel (C) and Screw (F) as shown. Do not Overtighten.

Step 2



a) Screw In Cam-bolt (A) into designated holes on Front Panel (8).
b) Insert Wood Dowel (C) into designated holes on Lower Divide Panel (7) as shown.
c) Attach (8) to (7) via Cam-bolts and Wood dowel.
d) Insert Cam-Lock (B) to the designated holes on (7), then turn clockwise to lock onto Cam-bolt. Do not overtighten.

Step 3



a) Screw in Cam-bolt (A) into designated holes on Middle Shelf (2).
b) Insert Wood Dowel (C) to the designated holes Lower Divide Panel (7).
c) Attach (7) to (2) via Cam-bolts and Wood Dowels.
d) Insert Cam-Lock (B) to the designated holes on (7), then turn clockwise to lock onto Cam-bolt. Do not overtighten.

Step 4



a) Insert Wood Dowel (C) to the desiganted holes on Lower Divide Panel (7).
b) Attach Bottom Panel (3) to (7) via Wood Dowels, then screw in the Screw (F) as shown. Do not overtighten.

Step 5

a) Screw in Cam-bolt (A) to the designated holes on Side Panels (4 & 6).
b) Insert Wood Dowel (C) to the designated holes on (2, 3, 8 & 10) as shown.



c) Attach Side Panels (4 & 6) to (2, 3, 8 & 10) via Cam-bolts and Wood Dowels.
d) Insert Cam-Lock (B) to the designated holes on (2, 3, 8 & 10), then turn clockwise to lock onto Cam-bolt. Do not overtighten.

Step 6

a) Screw in Cam-bolt (A) to the designated holes on Bottom Connect Bar (9).
b) Insert Wood Dowel (C) to the designated holes on (3, 4 & 6) as shown.
c) Attach (9) to (3, 4 & 6) via Cam-bolts and Wood Dowels.
d) Insert Cam-Lock (B) to the designated holes on (3, 4 & 6), then turn clockwise to lock onto Cam-bolt. Do not overtighten.



Step 7

a) Screw in Cam-bolt (A) to the designated holes on Top Panel (1).
b) Insert Wood Dowel (C) to the designated holes on (4, 5 & 6) as shown.
c) Attach (1) to (4, 5 & 6) via Cam-bolts and Wood Dowels.
d) Insert Cam-Lock (B) to the designated holes on (4, 5 & 6), then turn clockwise to lock onto Cam-bolt. Do not overtighten.



Step 8



Attach Top Connect Bar (13) to (1) by using Wood Dowel (C) and Screw (E).

Step 9



Attach Back Panel (11 & 12) by using Screw (D) as shown.

The assembly of the Storage Cabinet unit is complete.

TIPS:

Your suggestions and comments for Costway are really important to us!
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ **Great products so far**
February 24, 2018
Great product so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, Costway will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office:Fontana
UK office:Ipswich

COSTWAY
SHOP EASY. SAVE MONEY.