




COSTWAY®

**Please give us a chance to make it right and do better !**

Contact our friendly customer service department for help first.  
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana      UK office: Ipswich



## Contact Us !

**Do NOT return this item.**

Contact our friendly customer service department for help first.



US: cs.us@costway.com  
UK: cs.uk@costway.com

## USER'S MANUAL

### Portable Basketball Hoop SP37609

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



# Before You Start

Please read all instructions carefully and keep it for future reference.

## Warnings:

Attention: For home use only.

Attention: The product is not suitable for the children under 6 years

Danger: Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.

Danger: Lack of attachment may cause a risk of tipping or falling hazard.

## General Warnings:

⚠ The product must be installed and used under the supervision of an adult.

⚠ Read through each step carefully and follow the proper order.

⚠ Remove all packaging, separate and count all parts and hardware.
















⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.

⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.

⚠ Please check and maintain it regularly, and the most important part needs to be suspended, fixed, or anchored to the ground.

## Packing list

① x1  Backboard	② x1  Hoop	③ x1  Upper tube
④ x1  Mid-tube	⑤ x1  Lower tube	⑥ x2  Tripod
⑦ x1 M8×15  Adjustable screw	⑧ x1 M8×50  Link screw	⑨ x1 M8×55  Bracket screw
⑩ x4 M6×20  Backboard screw	⑪ x2  Wheel	⑫ x1  Stand base
⑬ x1 φ8×440  Axle	⑭ x2 M8×20  Base screw	⑮ x2  Spanner

## Remarks:

A.The screws ⑧、⑨、⑩、⑭ and ⑮ all are packed in one polybag.

B.The adjustable screw ⑦ is already installed on the Mid-tube ④.

## Product SPEC.:

### MODEL:

XY-BS218A

### Product dimension:

46.8"L x 28"W x 77.5"-101.5"H

### Backboard size:

28"L x 18"W

### Hoop size:

Φ15.3"

### Basketball stand base size:

28.7"L x 17.7"W x 5.5"H


### Capacity of base:

30 Liters

### Adjustable Height:

62.2"- 85.8"

(From basketball hoop to ground)



Please read the instruction carefully and follow it to use.

## WARNING:

- **The basketball stand is suitable for children over 6 years old.**
- **Children must use the basketball hoop under the supervision of an adult.**
- **IMPROPER INSTALLATION OR SWINGING ON THE RING MAY CAUSE SERIOUS INJURY OR DEATH.**
- **During play, do not wear jewellery (rings, watches, necklaces, etc). Objects may become entangled in the net.**
- **Check the product before each use for instability.**
- **Never put the stand on the base without water or sand, otherwise it may cause serious injury or death.**



Recommend to install this product by two adults.

## Installation Steps:

1. Check the accessories as per packing list.
2. Insert the axle (13) through the base (12) to hold the two wheels (11) and the lower tube (5).
3. Please fix the tripod (6) L and (6) R on the left and right sides of the base (12) respectively with screws (14) M8x20, and then fix the other end of tripod (6) L and (6) R to the lower tube (5) with screw (9) M8x55.

## Pay attention:

After completing the third step, please fill the base with water or sand immediately, and then install the other parts of the basketball hoop.

4. Connect the mid-tube (4) to the lower tube (5) with a link screw (8) (M8x50).
5. Assemble the hoop (2), backboard (1) and the upper tube (3) together with the backboard screw (10) (M6x20).
6. Insert the upper tube (3) into the mid-tube (4), align the screw holes of the two tubes according to the required size, tighten the adjustable screw (7), and then complete the installation.
7. Tighten all bolts with spanners (15).