


PATIOJOY



USER'S MANUAL 4 Pcs Patio Conversation Set HW64412

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.


Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway
Visit us: www.costway.com



**FLOOR AREA
2MX2M**



ASSEMBLED BY 2 ADULTS


Contact Us!

Do NOT return this item.


Contact our friendly customer service department for help first.



Before You Start




- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.




Board Identification


Not actual size



Left Arm x 2



Right Arm x 2



Back x 2



Seat x 2



Front Cross Bar x 2




Base Cross Bar x 2



Back Cross Bar x 2


Board Identification

Not actual size




Hardware List


Actual size




BOLT




BOLT




BOLT




BOLT



WASHER




ALLEN WRENCH



ADJUSTABLE
LEVELLERS

STEP 1


Insert adjustable levellers(T) to bottom of each Arm (A) by turning clockwise until secure.
Adjust height as desired.
Repeat step for the other side arm(B).



STEP 2


Attach the Cross Bar (E&G) to the arm (A&B).

IMPORTANT: Do not tighten completely until assembly is completed.




STEP 3

Attach the cross bar (F&G) to the arm(A&B) by inserting bolts (M) with washers (R).



STEP 4


Attach the seat (D) to the arm(A&B) and the cross bar(E&F) by inserting bolts(Q&P)with washers(R).



STEP 5


Attach the back (C) to the seat(D) by inserting bolts(N) with washers(R).

Attach the back (C) to the arm (A&B) and the cross bar (G) by inserting bolts(M) with washers(R).




STEP 6

Tighten all the bolts with the allen wrench, and turn the chair to the upright position. Your chair is now ready for use.



Maximum Loads




⚠ WARNING


This item is only suitable within the specified maximum load-bearing. Heavier loads than the indicated load capacity may cause instability, resulting in possible injuries.

Board Identification


Not actual size



Left Arm x 1



Right Arm x 1




Back x 2



Seat x 2



Front Cross Bar x 1




Base Cross Bar x 1



Back Cross Bar x 1


Board Identification

Not actual size




Hardware List


Actual size




BOLT




BOLT




BOLT




BOLT



WASHER




ALLEN WRENCH



ADJUSTABLE
LEVELLERS

STEP 1


Insert adjustable levellers(T) to bottom of each Arm (A) by turning clockwise until secure.
Adjust height as desired.
Repeat step for the other side arm(B).



STEP 2


Attach the Cross Bar (H&J) to the arm (A&B).

IMPORTANT: Do not tighten completely until assembly is completed.




STEP 3

Attach the cross bar (I&J) to the arm(A&B) by inserting bolts (M) with washers (R).



STEP 4


Attach the seat (D) to the arm(A&B) and the cross bar(I&H) by inserting bolts(Q&P)with washers(R).



STEP 5


Attach the back (C) to the seat(D) by inserting bolts(N) with washers(R).

Attach the back (C) to the arm (A&B) and the cross bar (G) by inserting bolts(M) with washers(R).




STEP 6

Tighten all the bolts with the allen wrench, and turn the chair to the upright position. Your chair is now ready for use.



Maximum Loads



⚠ WARNING

This item is only suitable within the specified maximum load-bearing. Heavier loads than the indicated load capacity may cause instability, resulting in possible injuries.

Board Identification

Not actual size




Table Top x 1





Table Leg x 2


Board Identification

Not actual size




Hardware List


Actual size




BOLT




BOLT



WASHER



ALLEN WRENCH




ADJUSTABLE
LEVELLERS

STEP 1

Insert adjustable levellers (T) to bottom of each Table leg(L) by turning clockwise until secure.


Adjust height as desired.

Repeat step for the other side Table leg(L).




STEP 2

Attach the Table Leg (L) to the Table Top (K) by inserting bolts (M&O) with washers (R).




STEP 3

Tighten all the bolts with the allen wrench,
and turn the table to the upright position.
Your coffee table is now ready for use.



Maximum Loads



WARNING

This item is only suitable within the specified maximum load-bearing. Heavier loads than the indicated load capacity may cause instability, resulting in possible injuries.

Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since Long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase. Following these important and helpful tips will enhance your furniture as it ages.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.



