



COSTWAY®

Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich AU office: Truganina



Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US: cs.us@costway.com
UK: cs.uk@costway.com
AU: cs.au@costway.com

USER'S MANUAL

Stroller Tricycle TQ10062

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

Please read all instructions carefully and keep it for future reference.

General Warnings:

- ⚠ Danger! Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.
- ⚠ The product must be installed and used under the supervision of an adult.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ Remove all Packaging, separate and count all parts and hardware before installation.
- ⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- ⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.

Picture for reference only. Please refer to the actual product.
The product should be assembled only by Adults


Suitable Age: 1.5-5 years old

Weight Capacity: 55 lbs

Feature

- Folding design. Compact size. More convenient to carry.
- "One Key" quick disassembly of rear wheels.
- Detachable awning with multi adjustable positions to avoid UV.
- Integrated backrest & Three-point safety harness for protection.
- Three using modes for different ages, accompanying children to grow up


Please read the manual before using this product, it will tell you the correct operation method and installation steps. To avoid damage to the product or injury to your child due to improper handling. This manual should be properly kept and easily accessible.




Parts List

Part	Description	Qty.
1	Music box	1
2	Handlebar cover	1
3	Handlebar	1
4	Head tube cover	1
5	Front tube	1
6	Bowl-shaped cover	1
7	Front fork	1
8	Front wheel	1
9	Footrest	2
10	Lower connecting tube	1
11	Upper connecting tube	1
12	Brake	2
13	Rear wheel	2
14	Rear frame	1
15	Rear frame cover	1
16	Rear push rod	1
17	Rear push handlebar	1
18	Canopy	1
19	Backrest cushion	1
20	Backrest	1
21	Guardrail	2
22	Safety belt	1
23	Saddle	1


Assembly Instruction




1.Remove all the packaging of the main body as shown in the picture.




2.Install 1.5V*3 battery on the music box and fix the battery cover, as shown in the picture. Then install the front music box on the handlebar and tighten it with 4 tapping screws of ST3.5 *15.




3.Open the guardrail as shown in the picture.




4.Lift the main frame body back and open it as shown in the picture.




5. Open the rear frame as shown in the picture.




6. Lock the guardrail as shown in the picture.




7. Attach the rear wheels to the rear frame as shown. Press it until you hear "Click" sound!



8. Unfold the footrest as shown in the picture. Press the folding switch of the footrest and gently pull the footrest down to the maximum angle (until you hear "Click" sound). Then unfold the footrest on both sides.




9. Install the rear push rod on the rear frame as shown (until you hear "Click" sound!) The rear push rod can be adjusted with three positions.




10. Install the canopy on the backrest as shown in the picture.


Instructions for Use




1. Infant Tricycle: Suitable for toddlers over 18 months.




2. Learn-to-Ride Tricycle: Suitable for toddlers over 24 months.




3. Classic Tricycle: Suitable for toddlers between 36-60 months.





4. Insert 3*1.5V AA batteries (not included) into the music box, and the battery installation must be done by an adult.




5. Two modes of front wheel clutch mechanism:

A: Set the front wheel locking device to , and the pedals will rotate when pushing.

B: Set the front wheel locking device to , and the pedals will not rotate when pushing.



6. The footrest can be folded and stored away according to different age of children's needs.




7. The opening width and installation angle of canopy can be adjusted according to your needs.


Folding Instruction



1. Open the guardrail as shown in the picture.




2. Press the folding button to fold the rear frame forward and up (until you hear "Click" sound).



3. Pull the main frame body forward close to the direction of front wheel.



4. Lock the guardrail as shown in the picture.



5. Fold the canopy downwards.



6. Adjust the rear push rod to the minimum height.

Warning

1. This product must be assembled by an adult; when a child is riding, the guardian must not leave;
2. Please carefully check whether the parts are connected well before the child uses the stroller;
3. This stroller is suitable for children aged 1.5-5 years old;
4. Keep away from fire: battery installation must be done by an adult;

5. When using the brake, push the tricycle back and forth to make sure that the brake is stopped;
6. To avoid suffocation, please keep the plastic covering (plastic bag) away from the baby;
7. Do not place any load on the vehicle, otherwise it will affect the stability of the vehicle;
8. Make sure that all locking devices are locked before using the stroller tricycle;
9. It is forbidden to use the stroller tricycle near stairs, thresholds, steps, or to play near heaters, stoves, etc., or to use it as a means of transportation in downtown areas or highways.
10. The stroller tricycle must be used in a flat and unobstructed place to ensure that it does not tilt during normal use to avoid injury;
11. The limit time for children to ride the stroller tricycle continuously for each time shall not exceed 1 hour. The maximum carrying capacity of the stroller is 55 lbs and the maximum carrying capacity of the carrying bag is 2.2 lbs. Overloading is strictly prohibited, and only for one baby to use alone.
12. Please read this manual carefully before use and keep it for future reference. If it is not used in accordance with this manual, it may affect the safety of children.

Cleaning and Maintenance

To avoid accidental injury to your child, please check and maintain the tricycle frequently:

1. When cleaning the tricycle body, please wipe it directly with a dry cloth;
2. Regularly add fixed lubricant to the corresponding positions of the transmission components, such as front and rear axles, handlebar shafts, etc., to improve the service life of the product;
3. Regularly check whether there are loose screws and damaged parts. If necessary, please replace the corresponding damaged parts;
4. When disassembling and assembling, please follow the instructions carefully to avoid unnecessary damage.
5. Regularly check whether the bolts at the joints of the handlebars and saddles are tight.