






COSTWAY®



USER'S MANUAL

Dressing Table Set HW62334

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com














Contact Us!

Do NOT return this item.


Contact our friendly customer service department for help first.



Before You Start



- Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- Keep the handtools close at hand. Do not use power tools to assemble your furniture.
 They may scratch or damage the parts.



Guide of Manual

- Please read the assembly and safety instructions thoroughly, and use the product in accordance with the intended purpose. It is recommended to save the manual for future reference. When offer the product to the third party, please transfer the manualsimultaneously.
- The texts and diagrams are illustrated as detailed as possible. For clarity, not all the details of every possible variation and installation methods canbe described. The texts and diagrams are given only as examples. If you require further information or face some problem, please contact and consult the seller.
- It is strictly prohibited to copy, sell, modify or translate this manual entirely or partially for any purpose without the express written permission of Songmics International GmbH. Songmics International GmbH reserves all rights.

Notes

- The product is intended for indoor use only, not for commercial use or outdoor use. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
- To prevent tipping over, the furniture must be fixed to the wall with the safety fitting provided. Different wall materials require different types of fixing devices.
- If needed, please purchase the suitable fixing devices at local retail store.
- Pleasecheck if the table is intact and if the components are complete before assembly. Do not place the edge of the unwrapped components on the floor to avoid the fray or damage.
- It is recommended that two adultsfinish the assembly. To avoid damaging the product, please assemble the unit on the flat, clean and soft floor.
- Follow the assembly steps shown in the diagram to position and adjust the parts, then gradually tighten all screws.
- We do not suggest to use electric drill for inserting the screws. It may damage to the product. Please use hand screwdriver (not supplied).
- After the assembly, please place the dresser table in a ventilated area. The odour will disappear after two days.
- Periodically check the firmness of all the screws and connected position.
- Nevertouch with sharp objects or corrosive chemicals, which may spoil the surface of the table.
- Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up the spills immediately and ensure that a mat or pad is placed under paper if you are writing.
- Protect the article from sunlight exposure or rain, and do not put itin a humid place. It mayaccelerate the distortion, discoloration or fuissure.
- Do not store heavy objects in the drawers. It may cause the article deformed or the paint flake off. After the assembly, please do not shake or strike the table to avoid the components deformed or falling apart.
- Please seek assistance and take care when moving the furniture. Prohibit rudely dragging the table as careless handling
 may case the damage or injury.
- It is recommended that before moving to a new location the dresser table is completely disassembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings after the disassembly.
- For daily care, please use a soft cloth with neutral detergent if necessary, then dry the surface.

Warning


- If the piece of thefurniture tips over, itmay result in serious or fatal injury.
- Never use the dresser table if any part is missing or defective. Otherwise, there will be the risk of injury.
- The product is not intended for children. Childrenmust be under adultsupervision to use the product. Never allow children to climb or play around the product, in order to prevent the product tipping over and mirror body being broken, and protectchildren from personal injury.
- During the assembly process, keep small objects out of the reach of children. It may be fatal if swallowed or inhaled.
- To avoid danger of suffocation, keep the plastic bag away from babies and children.

PARTS LIST


	TAIRTO EIGT	
A1 16×	A2 4×	A3 6×
() mmmmm	()	
Ф6×40mm	Ф3.5×30mm	Ф3×25mm
A4 2×	A5	B1 16×
Ф4×50mm	1×	Ф8mm
B2 4× Φ6mm	C 1×	D
2×	F 1×	G 2×
H	1	J 2×
K	L 1×	S1 11×
S2 1×	S3	S4

PRODUCT ASSEMBLY

STEP 1




STEP 2







PRODUCT ASSEMBLY


STEP 3






STEP 4






PRODUCT ASSEMBLY


STEP 5



STEP 6








PRODUCT ASSEMBLY

STEP 9



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting. Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area. Using solvents of any kind on your furniture may damage the finish. Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase. Following these important and helpful tips will enhance your furniture as it ages.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

