

USER'S MANUAL


Vinyl Real Estate Sign Post OP3931

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP!

**FLOOR AREA
4MX4M**



ASSEMBLED BY 1 ADULT

Follow Costway
Visit us: www.costway.com




Contact Us!

Do NOT return this item.


Contact our friendly customer service department for help first.



Before You Start



- Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- Work in a spacious area, preferably on a carpet close to where the unit will be used.
- Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.




Board Identification

Please read through before starting assembly.









IMPORTANT: CHECK THE INSIDE OF THE LARGER PIECES IN YOUR BOX FOR OTHER MATERIALS PACKED INSIDE.

Check Box for These Contents

In the event of missing or defective parts please contact our service department



Box Contents List


<div></div> <div>For 4"x4" Post</div> <div><div>A</div><div>× 1</div></div> <div>Post Cap</div>	<div></div> <div>For 4"x4" Post</div> <div><div>B</div><div>× 1</div></div> <div>Arm Key</div>	<div></div> <div>For 2"x3.5" Arm</div> <div><div>C</div><div>× 2</div></div> <div>Rider Clip Kit</div>	<div></div> <div>For 2"x3.5" Arm</div> <div><div>D</div><div>× 2</div></div> <div>Arm Cap</div>
<div></div> <div><div>E</div><div>× 2</div></div> <div>Sign Clip Kit</div>	<div></div> <div><div>F</div><div>× 1</div></div> <div>2"x3.5"x36" Arm</div>		
<div></div> <div><div>G</div><div>× 1</div></div> <div>4"x4"x72" Post</div>			
<div></div> <div><div>H</div><div>× 1</div></div> <div>4"x4"x36" Stake</div>			

Tools You Will Need

- Level
- Hammer


Step 1

Use a hammer to drive the Steel Anchor into ground. Make sure that anchor is straight while hammering. The anchor should be driven downwards until the bottom plate is flush with the ground. The bottom plate should be facing forward in the desired direction of real estate post arm.




Step 2

Slide the vinyl real estate post over the anchor until it touches the ground. The hole on the post should be at the top and facing in the desired direction of the sign arm.





Step 3

Use a screwdriver and attached screws to fix the rider clips on top of post arm.



Step 4

Slide the vinyl Arm into the post. Make sure that the rider clips are facing up. Slide the arm through the holes until the slots are aligned on the inside of the post.




Step 5

Step 5


Slide the key into the slots of the real estate post arm until it locks in place. This will secure the arm.

Step 6

Slide the post cap onto the top of the real estate post. And slide the rail cap onto both side of the arm.



Step 6




Step 7

Step 7


Insert the sign clip screw through the arm, and then fix the screw.

Note: You need to choose the right hole on the arm to fit the size of your signs

Hole distance option 1:



Hole distance option 2:



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment.

Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase. Following these important and helpful tips will enhance your furniture as it ages.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us!

We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you **EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!**

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

