


10 VIBRATING MOTORS

5 modes 3 strength



USER'S MANUAL

MASSAGING MAT WITH HEAT
EP24407

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!



SPECIAL NOTES:

1. The Massage cushion will auto-switch-off in 30 minutes for safety precautions, you may reactivate the massage cushion by pressing the power button again.
2. For in-car use, we strongly suggest to unplug the massage cushion when you park the car for safety precautions.

US office: Fontana, California

UK office: Ipswich

Manual Mode

You may press M1 – M4 buttons to select the areas you would like to do massage:

Press **M1** key activates shoulders vibration massage mode

Press **M2** key activates upper back vibration massage mode

Press **M3**key activates lumbar/lower back vibration massage

Press **M4** key activates butt and thighs vibration massage

Troubleshooting Guide

Problem	Possible cause	Solution
If the unit does not turn on when you press the power button ?	<ul style="list-style-type: none">·Poor power connection·Wire tangled·Damaged controller or massage cushion·Plug not inserted into the jack properly	<ul style="list-style-type: none">·Reconnect the AC power or DC power and the connector of massage cushion (Check and clean up any dirt in the connector)·Reorganize the wire·Contact our customer service for solution·Turn off the unit and insert the plugs correctly
During the session, the heater vibration becomes weak or stop completely	<ul style="list-style-type: none">·Massage cushion slides off·Damaged controller or massage cushion·Poor connection·Program error	<ul style="list-style-type: none">·Turn the unit off, firmly reattach the massage cushion·Contact our customer service for solution·Reconnect the AC power or DC power and the connector of massage cushion (Check and clean up any dirt in the connector)·Reconnect the AC power or DC power and restart the session
The skin where attached massage cushion turns red and irritated	<ul style="list-style-type: none">·Intensity is too high·Session time to long	<ul style="list-style-type: none">·turn down the speed intensity·Reduce session time

Specifications

- Input: 100-240V AC
- Output: 12V / 1.5A DC
- Power: 18W
- Material: 100% Polyester
- Unit Size: 120cm x 52cm x 5cm

INSTRUCTIONS

Please read the following instructions before using the product

1. Do not use the device after meal.
2. Children should not play with the appliance. Close supervision is necessary when any appliance is used near children.
3. People who are pregnant, illness or under treatment should consult by physician first.
4. Do not use on an infant or on an animal.
5. This product is not to be used on or by an invalid, sleeping, helpless or unconscious person,a person with poor blood circulation or insensitivity to heat.
6. Unplug when not in use. Never leave appliance unattended, especially if children are present.
7. After use and before cleaning, make sure the power sources be turned off.
8. Do not tug and pull the device by the supply cord.

9.Check the device before using, do not use if there is any defective or running abnormal while using.

10.Do not assemble or repair the device by yourself, contact our customer service for solution.

11.Only use the soft and dry cloth to clean and wipe the device.

12.Keep away from high temperature environment and fire.

13.Do not expose the device direct in the sun.

Specialty

1. An easy way to reduce stress on your body from travel, work and other stress factors.

2. 10 massage motors provide soothing relief on your shoulders, back, lumbar and thighs.

3. Vibration massage setting with 3 speeds.

4. Easy-to-use hand controller with storage pouch.

5. Adjustable straps secure to your seat.

6. Soothing heat treatment in back and seat partsfor more intensive relief.

7. AC & DC adapter for home, office and car use. (both included)



Operation

Connect the adapter with device to the power source.

Presses **Power** key and Power indicator is light up.

Auto-mode

Press **PROGRAM** button to select 1,2,3,4,5 to switch between 5 different massaging vibrating modes to relax the muscle, relieve fatigue.