


COSTWAY®










USER'S MANUAL

WOOD TOP WORKBENCH TH10020NA

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

-  Please read all instructions carefully.
-  Retain instructions for future reference.
-  Separate and count all parts and hardware.
-  Read through each step carefully and follow the proper order.
-  We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
-  Always place the product on a flat, steady and stable surface.
-  Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

WORKBENCH SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



CAUTION

Please take safety precautions when using the workbench.


- Do not step or climb on worktop.
- Do not let children near the workbench.
- Before setting workbench upright, verify that the same number of adjustment holes are visible on each leg to ensure that the workbench will be level.
- Use two or more people to move and assemble workbench.
- Failure to do so can result in back or other injury.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

WORKBENCH CARE

1. Wash the workbench with a mild detergent and warm water. do not allow water to remain on the workbench for any length of time.
2. Rinse completely and dry thoroughly.

PARTS




F1 (22 PCS)



F2 (22 PCS)



F3 (30 PCS)



F4 (8 PCS)


ASSEMBLY INSTRUCTIONS

Workbench Use Requirements


- > Intended for use in a garage.
- > Maximum weight limit is 1, 760 lbs (800 kg) for the workbench.

Assemble Workbench Frame


Step 1




Step 2




Step 3




Step 4



Step 5



Finish



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.



Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana

UK office: Ipswich

DE office: Hamburg

FR office: Saint Vigor d'Ymonville

PL office: Gdańsk

Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



US: cs.us@costway.com

UK: cs.uk@costway.com

