



COSTWAY®



USER'S MANUAL
Floor Lamp End Table
EP24507US / EP24508US

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.




Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.


Please read this manual carefully before assembly. Check parts and components and make sure they are correctly identified.

A	cross wrench	1 PC
B	Phillips head screw	4 PCS
C	double-headed screw	4PCS
D	lamp bracket	1PC
E	iron tube and lamp holder	1PC
F	tabletop panel	1PC
G	upper stand	4PCS
H	middle shelf panel	1PC
I	lower stand	4CS
J	bottom panel	1PC
K	decorative round head nut	1PC
L	Velcro magic	2PC
M	EVA gasket	4PCS
N	lampshade	1PC
O	hollow-carved designed side panel	2PCS (The white one has no side panels)



Note: A soft cloth must be placed on the ground for the product before assembly, so as not to scratch the panel surface and affect the appearance.



Aim at the hole position of the tabletop panel (F), assemble the upper stand (G), and put the side panel (O) into it along the pull groove.



Connect the middle middle shelf panel (H) to the upper stand (G) with the double-headed screw (C), then assemble the lower stand (I).



After assembling the iron tube, lock the lamp bracket to the lamp holder, and then lock the lampshade to the lamp bracket with the decorative round head nut (K). Finally, fix wire to the lower stand (I) with Velcro magic (L).

Ps: KD lampshade assembly parts KD lampshade assembly instructions.

The assembly is completed as shown in the picture on the left. Now it can be safely used. It is recommended to use no more than 100W incandescent bulbs.

Do not sit or stand on the table top of the lamp

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us!

We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.

