











Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

US office: Fontana UK office: Ipswich





Contact Us!

Contact our friendly customer service department for help first.

Do NOT return this item.



USER'S MANUAL

Kids Ride On Motorcycle TY327441





Before You Start

Please read all instructions carefully and keep it for future reference.

Warnings:

Attention! Use it with protective equipment.

Attention! Not use it in the traffic.

Attention! The product is not suitable for the children under 3 years.

General Warnings:

- The product must be installed and used under the supervision of an adult.
- A Read through each step carefully and follow the proper order.
- A Remove all packaging, separate and count all parts and hardware.
- ⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- ⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.
- ⚠ Please use this product with caution. The use of this product requires superb skills to avoid accidents to the user or others due to a fall or collision.
- ⚠ Please wear suitable protective equipment during use, e.g. protective helmet, gloves, knee pads, elbow pads etc.

Table of Contents

Brief Instroduction And Models

Important Safety Instructions

Parts List

Battery Line Connector

Assembly Steps

How To Operate Your Vehicle

Charging The Vehicle

Caring For Your Vehicle

Problems And Solutions Guide

Disposal Of Battery

Additional Explanation

Brief Instroduction And Models

Thank you for choosing our vehicle. Each vehicle pattern is designed upon a unique mold: such as the realistically imitated vehicle and cute series, which bring different fun and feeling for your children.

We wish our vehicle to accompany your children for a happy childhood and your family will be filled with joy and happiness.

Suitable Age:	37-95Months	Load Capacity:	<25 kgs
Motor	390/6V/13000RPM	Size Of Car:	106*50*82cm
Charger:	Input: 100 -240V 50/60Hz Output: DC6V 500mA	Battery:	6V4.5Ah
Power Way:	Charging Type	Charging Time:	8-12 Hours
Fuse:	7A	Average Battery Life;	Approximately 300 Times

Manual book only for your reference, all configuration based on your order!

Important Safety Instructions •

Read carefully and follow all the instructions

Assembly/Used

! WARNING ! CAUTION



Product requires adult assembly. Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state.



Care should be taken in unpacking and assembly of the vehicle. Children should not handle parts, or help in assembly of the vehicle.



Be sure to properly dispose of the protective materials and plastic bags before assembling. Children are forbidden to play with these packaging materials, as there is a danger of suffocation!



Suitable for age 37-95months; Maximum user weight is 25 kgs.



Choking hazard---small parts. This product is forbidden to children under 3 years.



Direct Adult Supervision Required. Never leaver chlid unattended by himself.



Always keep child in view when he is in vehicle. Teach appropriate safety rules to your child before allowing operation of this vehicle. These rules should also be reviewed with other playmates who want to drive this vehicle. Make sure children know and follow these rules for safe driving and riding:

- -Always wear shoes;
- -Always sit on the seat;
- -Always wear a helmet when riding;
- -Only one rider at a time.



Keep children within safe riding areas, these areas must be:

- A Away from steps/cars/driveways/roads and alleys;
- B Away from sloped/inclined surfaces/swimming pools or other bodies of water;
- C Away from other dangerous places;
- D Only outdoors. Generally flat gound/playground/Garden asphalt and other hard surfaces;

Never use in the dark. A chlid could encounter unexpected obstacles and have an accident. Operate the vehicle only in the daytime or a well-lit area.



Before use, adults should check whether the main components are in good condition:

- Plug in the battery plug and turn on the power
- Check whether the battery/charger/wire/plug/body and other parts are damaged; whether the screws are loose; whether there are other damage problems.
- Avoid using damaged cars before repairs.
- To avoid damage to the motor and gears, please stop before switching from the forward switch to the reverse switch.
- Please turn the forward/stop/reverse switch to "O" when not driving.
- Turn off the power switch. (Note: This switch only controls the driving part.)
- When the car is driving, do not let any children touch or get close to the wheels.
- Do not tow or overload anything behind the vehicle, and do not exceed the maximum load capacity of 25 kg.

№ WARNING:



Never leave child unattended.

<u></u> MARNING:



Avoid serious injury from falling or sliding out.

MARNING:

 \wedge

Parcels or accessory items, or both, placed on the unit may cause the unit to become unstable.

Important Safety Instruction

Battery/Charger



Batteries/charger/alkaline batteries are not toys and children are forbidden to play.



Never short-circuit the battery terminals.



Use only with manufacturers prescribed rechargeable battery and charger.



Do not use the battery or charger for any other product. Could cause overheat - ing, fire or explosion.



Do not open the battery and the charger



Do not charge battery upside down.



Always maintain battery dry. Do not let the vehicle contact fresh water or salt water.

Charge



Charge 4-6 hours before the first time using, but not charge over 10 hours.



Only adult can handle or charge the battery. Never allow children to do that. Turn off power switch before charging the battery.



Connecting correct polarity when charging.




Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the charger or the battery until you have replaced the worn or damaged parts.


- When the vehicle's s normal speed apparently slows down or after each use, recharge the battery for 8-12 hours, never charge the battery longer than 18 hours.
- Charge the battery in a dry area ONLY.
- It is normal that charger and battery are tepid while charging.
- Charge the battery at least three months one time, even if the vehicle has not been used.
- When the room temperature is lower than 5 degrees Celsius, the actual charging time will be extended by 3-5 hours. Please do not use this product below -5 degrees Celsius.

Packing List


Please identify all parts before assembly and save all packaging materials until assembly is complete.



Battery Connector




Connecting the Battery Line Inserting red wire on the car into red column on the battery. Inserting black wire on the car into black column on the battery. (Avoiding inserting into the uncorrect polarity)




Assembly Steps

Please note before using the product, must assembled by adult.



How To Operate Vehicle

Note! 1.when changing the tap postion, please make sure the vehicle has completely stopped, otherwise it will damage the gear box and motor.



All switches are in the front of the vehicle seat.

Power switch: Turn right to start the toy car, turn left to close the toy car.

- Forward
- 1. Press the "forward-backward switch" on the "forward" position.
- 2. Press the "foot pedal", the vehicle drives forward.
- Stop

The vehicle will brake automatically, when your child's foot is lifted from the "FOOT PEDAL".

- Reverse
- 1. Press the "forward-backward switch" on the "backward" position.
- 2. Press the "foot pedal", the vehicle will go backwards.
- High-low Speed

Press the "high-low speed switch" on the "high" position, the car will go fast.

Press the "high-low speed switch" on the "low" position, the car will go slowl


Pls note for high-low speed and mp3 funciton just for your reference, all configuration depend on your order!



Do not close to the ear, improper use can cause hearing damage.

Charging







Open the charger cover

- 1. Plug the charger port into the input socket.
- 2. Plug the charger plug into a wall outlet, and the battery will begin charging.

Caring For Your Vehicle •

- 1. Vehicle body is modeled by polypropylene. Solarize or in -15°C use are strictly prohibited. Vehicle should be far away from hot objects, like an oven and heater, plastic parts may melt beside.
- 2.Avoid operating the vehicle in wet or snowy conditions, and do not spray the car with a hose. Do not wash the vehicle with soap and water. Washing motors or electrical switches can cause them to corrode and can cause switch or motor failure.
- 3.Avoid operating the vehicle on sand, loose dirt or gravel. Sand, loose dirt or gravel in the motors or electrical switches can cause them to jam, and could cause switch or motor failure.
- 4. The vehicle can be wiped down with a soft, dry cloth for a shiny finish, you can wipe plastic parts with a non-wax furniture polish applied to a soft-cloth. Do not use automotive wax. Do not use soap or water or spray the vehicle with a hose.
- 5.Do not modify the electrical system. When the fault appears and they must be maintained by professional.Alterations could cause a fire resulting in serious injury and can also ruin the electrical system.
- 6.Use for about half month, check the wheels turning agilely or not, motor work is normal or not. Using infused lube to lubricate moving parts.


Problems and Solutions Guide •

Problem The vehicle does not run

Cause:The battery may low on power.
 Afer each use and once a month minimum, charge the battery for 8-12 hours

Problems And Solutions Guide

Cause: Thermal fuse has tripped. The vehicle is equipped with a self-resetting fuse.
 When the vehicle is overloaded or operated incorrectly, the selfresetting fuse will be cut off for 1 minute before becoming operational again. The self-resetting fuse is under the seat(refer to the picture)



- Cause: battery connector or wires are loose
 Make sure the battery connectors are firmly plugged into each other.
- Cause: battery is dead
 Please contact our customer service.
- Cause: electric system is damaged
 Please contact our customer service.
- Cause: motor is damaged
 The motor needs professional repair. Please contact our customer service.

Problems: The battery will not recharge.

- Cause: battery connector or adapter connector is loose.
 Make sure the battery connector and adaptor are firmly plugged together
- Cause: charger is not plugged in.
 Make sure the charger is plugged into the wall outlet and the power flow to the outlet is on.

Cause: charger is not working
Is the charger warm while charging? If not, the charger may be broken and please
contact our customer service.

Problem: The vehicle does not run very long

Cause: battery may be undercharged
 You may not charge the battery long enough. After each use, or once a month minimum, charge the battery for 8-12 hours. Do not charge over 18 hours.

Disposal Of Battery



- Do not throw into a fire. The battery may explode or leak.
- Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.
- Return an exhausted battery to your local approved lead-acld battery recycle.

Special Explanation ⊙



- 1. The product is not a means of transportation, do not drive on the street, using the product under adult's guardianship.
- 2. Do not allow children under 36 months s to use the product.
- 3. Overage and overload are forbidden. Maximum load:25 kgs.
- 4. The car should be assembled and checked by adults, guarantee safety before using.
- 5. Do not wash the product with water, wiping the car using a soft wet cloth only.
- 6. Battery charging should be handledy adult only, the charger is not toy, do not let children play the charger.
- 7. It is strictly forbidden to drive in dangerous areas such as public avenues, streets, slopes, poolsides, and stairs.
- 8. Do not use this product in high-voltage line, transformer station, gas station, hospital.
- 9. Children must wear shoes when using this product.
- 10. Please read carefully and keep this manual book for your children's safety.
- 11. In order to prevent a child from suffocation, keep plastic bags away from children.

Concluding remarks

Operative norm: EN71-1 EN71-2

EN71-3 EN62115

The illustration adopted in the explanation is used for explaining product's operating measures and configuration. When there is little difference between assembly diagram and practicality, according to the real object please.

Improvement in vehicle will be added to the manual of new edition, there is no extra information. The company reverse the right to change the manual of its models at any time.

At least, thank you for purchasing our products. We will provide you comprehensive services wholeheartedly. May your family live a happy life and your baby grow up happily.

WARNING: To reduce the risk of injury, adult supervision is quired.

Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water; always wear shoes, and never allow more than 1 rider(s).