




COSTWAY®

Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich AU office: Truganina



Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US: cs.us@costway.com
UK: cs.uk@costway.com
AU: cs.au@costway.com

USER'S MANUAL

Wooden Sandbox TS10041

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

Please read all instructions carefully and keep it for future reference.

General Security Warning

Caution: The Product is not suitable for the children under 3 years

Danger: Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.

Danger: Lack of attachment may cause a risk of tipping.




WARNING:
CHOKING HAZARD-Small parts.
Not for children under 3 years.


Warning for Assembly

- ⚠ Assembled only by adults
- ⚠ Remove all Packaging, separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.


PART LIST




Ⓐ x2



Ⓑ x2




Ⓒ x2




Ⓓ x2




Ⓔ x8



Ⓕ x2



Ⓖ x2



Ⓗ x2



Ⓘ x6



4x35mm

Ⓙ x48




4x25mm

Ⓚ x16




3x15mm


Ⓛ x36




Ⓜ x6


- 1** Use screw J to connect part A and B. Holes on the part A face outward.


4x35mm
J x8





- 2** Use screw J to connect part C and D. Holes on the part C face outward.


4x35mm
J x8





- 3** Use screw K to connect E to the main frame. Holes on the part E face inward.


4x25mm
K x16




- 4** Use screw J to attach part F. Holes on the part F face upward.




4x35mm
J x12





- 5** Use hinge M to connect part G and H and secure it with screw L. Assemble two sets!



- 6** Attach part I to part H, and secure it using screw J. Assemble two sets!



- 7** Put the assembled part in step 6 to the main frame. Use screw J to fix.



- 8**

