

TIPS:

Your suggestions and comments for Costway are really important to us!

We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:


★★★★ Great products so far

February 24, 2018
Great product so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, Costway will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office:Fontana
UK office:Ipswich







Children Bed HW59101






PRODUCT ASSEMBLY

Read all instructions before assembly and use.
KEEP INSTRUCTIONS FOR FUTURE USE.
Due to the presence of small parts during assembly, keep out of reach of children until assembly is completed.


CAUTION


DO NOT use this bed without a mattress. Infants who cannot get in and out of a twin bed without help can be trapped between a mattress and a wall and suffocate. NEVER place infants in twin beds with or without guardrails in place. NEVER use bed with children under 3 years. Never place bed near windows where cords from blinds or drapes may strangle a child. Do not place items with a string, cord, or ribbon around a child's neck, such as hood strings or pacifier cords. Do not suspend strings over a child's bed for any reason.

PARTS




PRODUCT ASSEMBLY





Align F -Frame side and G-Frame side with wooden center leg(C), fasten with washers (K) and screws (P). Align brackets (M) to the end of side boards (F)(G), fasten with washers (K) and screws (J)



Align assembled side frame to Headboard (A), and attach with washers (K) and screws (J).

Do not tighten screws completely.

Align assembled side frames to Footboard (B), and attach with washers (K) and screws(J).

Tighten all screws for steps 3 and 4.

PRODUCT ASSEMBLY

