

USER'S MANUAL Baby Playard BB0511

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway













Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

Please read all instructions carefully and keep it for future reference.

General Warnings:

- ⚠ Danger! Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.
- ⚠ The product must be installed and used under the supervision of an adult.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ Remove all Packaging, separate and count all parts and hardware before Installation.
- ⚠ Please ensure that all parts are correctly installed, incorrect Installation can lead to a Danger.
- ♠ Ensure a secure surface during construction, and place the product always on a flat, steady and stable surface.

How To Set Up Your Camp Cot

STEP 1: Unzip and remove carry bag (Fig. 1), then remove the mattress base by unfastening the Velcro straps (Fig. 2), and take out the Camp cot





Fig.1:

STEP 2: Widen the 4 legs as shown in the diagram. (Fig 3)

Note: The difference in the size of the "V" made by the short and long rails.



STEP 3: Starting with the shorter sides, pull up quickly and in the center of each rail lock them in place. (Fig. 4) Pull upward the long rail from the middle joint until they lock into a flat poistion. (2)

Note: Rail locks are in the center of each rail and covered by fabric.



STEP 4: Push the center folding lever downwards until it locks in position. (Fig. 5)




STEP 5: Put the mattress base into the Camp cot and fix the Velcro fasteners under the mattress onto the base. (Fig. 6)




How To Fold Your Camp cot:

STEP 1: Remove the mattress from the Camp cot and pull the center folding belt (Red Level belt) upwards to a minimum of a 2/3rd Position. (Fig. 7)




STEP 2: Press the button of the center joint of the 4 hand rails and press the rails down to a "V" position. (Fig. 8)


Note: Before pressing the button, pull up the center joint of the top rails.



STEP 3: The joint of the rail must go down on both sides as shown before you can fold the system (Fig. 9).



STEP 4: If the joint of the rail goes down only on 1 side (Fig. 10), then the process must be repeated again..



STEP 5: Arrange the four legs properly and then place the camp cot in the mattress base and fasten with the velcro straps as shown in the diagram. (Fig. 11 & Fig. 12)




Fig 11.:

ZIPPER SECOND LAYER ASSEMBLY:

- 1. Take out the zipper second layer
- 2. Attach the zipper together (pic1. 2)



3. Close the zipper around the whole camp cot (pic.3. 4)



4. Then put the fabric on the zipper and fasten it with Velcro (pic 5)



5. Now take out the two tubes, and push the ends of the steel supports into the textile tunnel. Then attach the tubes. (Pic 6. 7.8)



6. Finally put the mattress on the second layer.(pic 9. 10)



Storage rack Assembly:

1. Take out the changer and 2 plastic hooks (pic 1)



Hold the hooks and place them in the holes on both sides (Pic 2.3). Please make sure the direction of the hook is facing outward.





3. Then put the storage rack on the rails of the camp cot (pic 4).



Changer Assembly:

1. Take out the changer and 4 tubes (pic 1)



2. Put the 2 long tubes on the back side of the changer (pls be sure that the hole direction is correct) (pic 2).



3. Put the tube with the plastic hook to connect the long tubes on one side, then the other side.


Attention: The plastic hooks face the forward direction. (indicated by arrow). (pic 3.4.5).





Music Center toy bar Assembly:

1. Take out the music center toy bar (PIC 1).



2. Connect part 1, 2 and 3 (pic 2. 3.4.5)









3. Connect part 4. 5 .6 7(pic 6.7)





4. Then put 3 toys on the frames (pic. 8. 9.10)







5. Then put the music center toys on the head or foot rails of the camp cot (pic.11.12.13)







Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating ★★★★★

