





# **COSTWAY**®



# **USER'S MANUAL Snow Cone Machine** KC41088

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

#### Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

**Follow Costway** Visit us: www.costway.com









# **Contact Us!**

#### Do NOT return this item.

Contact our friendly customer service department for help first.



# **Before You Start**

- Please read all instructions carefully.
- Retain instructions for future reference.
- Seperate and count all parts and hardware.
- Read through each step carefully and follow the proper order.
- We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- Caution: Read the warnings carefully. Avoid kids get touch of small parts or plastic bag.

#### **Brief Introduction**

The stainless & acrylic snow cone machine is mainly used for crushing big ice into small ice, usually applied to cold drinks series, also applied to slicing up popular foods(fruits and vegetables). This product is made from full stainless steel ice crusher and acrylic box, which is antirust, safe and environmentally friendly and so on. It adopts vacuous double layer stainless technique, which won't waste the cold energy. The acrylic box helps to keep the ice cold, health and hygiene.

## 1. Main parameter:

Model	KC41088
Dimension	1.6" × 1.2" × 2.1"
Heating power	200W
Voltage	110V
Frequency	60Hz
Speed	1400 R/M

#### 2. Structure of machine





### 3. Preparation

- 1. Please read the specification carefully and know its structure, function, main condition and safe operation requirement before you use it, so that you can make the best of this equipment to raise your efficiency.
  - 2. After you open the carton package, please clean it by wet towel.
- 3. Please make sure the voltage is same with the machine and power socket is safe and the protection of switch is installed before using.

## 4. Operating instructions

- 1. Open ice crusher cover, wipe ice tank with dry cloth, check whether the blade is firmly installed.
- 2. Check the power line and plug to insure the circuit contact in good condition and avoid creep age, then close the switch and plug in the ice crusher.
- 3. Open the cover of ice crusher, and put in some ice in the right amounts, then cover it.
- 4. Press the switch to start the ice crusher, depress the handle to push the ice to edge of ice crusher.
- 5. It is better to use these ice with the diameter 4-5cm, or you can break up the big ice to small one to use.

#### 5. Attention

- 1. To use single-phase 110V voltage.
- 2. Children are forbidden to use this machine. Regardless of any circumstance, do not touch the steel plate when working.
- 3. You must use a ground socket; keep cable away from the heat; do not connect the cable and electrical sockets to water or other liquids; do not use the damaged cables, power plugs and sockets.
- 4. To be put on a flat place, the ice should be put into evenly; otherwise it would cause the fuselage vibration.
  - 5. The ice volume should be controlled below the red line of 1cm in ice tank ice.
  - 6. Please only use cloth scrub the ice tank, but not water cleaning.
  - 7. Please clean the rest water in the ice tank after using.
  - 8. Do not touch the blade when cleaning to avoid scratching your fingers.



- 9. Do not arbitrarily dismantle electromotor, when cleaning or repairing machine, you should first turn off the power switch and pull plugs, can not keep the machine running empty for an hour.
- 10. The machine can not be cleaned by detergents, avoiding the corrosion of chemical substances to machine. It also can not be directly washed with water, with avoidance any damage to electrical components as well as machine.


#### 6. Electrical data

L-----3X0.75 copper conductor

K-----15A/110V switch

Fu----5A fuse

M-----Electric motor





### Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

**UK office: Ipswich** 



- \* Reward Points
- \* Exclusive Customer Service
- \* Personalized Recommendations
- \* Permanent Shopping Cart
- \* Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

