






USER'S MANUAL Kitchen Island HW60456


PRODUCT ASSEMBLY




PRODUCT ASSEMBLY










PRODUCT ASSEMBLY

10


Attach the part 1 tabletop with six part A cam bolts, six part C dowels, and six part B cam locks. Turn the cam locks to secure the tabletop.



A 6 PCS
B 6 PCS
C 6 PCS

11


Attach a part G handle to a part 15 left door with two part H screws. Attach a part N metal plate with a part D screw. Repeat to attach handles/metal plates to another part 15 left door and two part 16 right doors.




D 4 PCS
4 PCS
H 8 PCS
N 4 PCS


12

Attach eight part M hinges to left/right doors with sixteen part D screws, two screws per hinge.



D 16 PCS
M 8 PCS







TIPS:

Your suggestions and comments for Costway are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2018

Great product so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, Costway will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office:Fontana UK office:Ipswich



