

USER'S MANUAL

Baby Playard BB0480

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com











Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

Please read all instructions carefully and keep it for future reference.

General Warnings:

- ⚠ Attention: To prevent possible injury by entanglement, remove this toy when the child starts trying to get up on its hands and knees in a crawling position.
- ⚠ Danger! Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.
- $\ensuremath{\Delta}$ The product must be installed and used under the supervision of an adult.
- A Read through each step carefully and follow the proper order.
- ⚠ Remove all Packaging, separate and count all parts and hardware before Installation.
- $\underline{\wedge}$ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during construction, and place the product always on a flat, steady and stable surface.

△ WARNING

Playard Warnings

WARNING: Failure to follow these warnings and the instructions could result in serious injury or death. This product including side rails, must be fully erected prior to use. Make sure latches are secure.

ASUFFOCATION HAZARD

INFANTS HAVE SUFFOCATED:

- In gaps between a mattress too small or too thick and product sides
- On soft bedding Never add a mattress, pillow, comforter, or padding. Use only the mattress provided by manufacturer.
- The playard mattress/pad is specially designed to prevent suffocation. The playard mattress/pad has a solid base, which must be at least 40 in. long and 28 in. wide and not more than 1 in. thick in order to meet safety standards. Using a thicker or a different sized mattress/pad may allow a child's head to get between mattress/pad and the side of the playard causing suffocation.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their back to sleep, unless otherwise advised by your physician.
- ALWAYS place child on back to sleep.
- NEVER use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.
- NEVER use a water mattress with this product.

FALL HAZARD: Always check that the bassinet is securely locked on the base/stand by pulling upwards on the bassinet.

MARNING: STRANGULATION HAZARD:

NEVER LEAVE INFANT IN PRODUCT WITH SIDES DOWN. Infant may roll into space between pad and loose mesh side causing suffocation.

 Strings can cause strangulation! NEVER place items with a string around a child's neck such as hood strings or pacifier cords. NEVER suspend strings over playard or attach strings to toys.

⚠ WARNING

 NEVER place the playard near a window where cords from blinds or drapes can strangle a child.

 Child can become entrapped and die when improvised netting or covers are placed on top of a playard. Never

add such items to confine child in playard.

 NEVER leave child in product with sides lowered. Be sure sides are in raised and locked position whenever child is in product.

WARNING: See playard floor and side rails for warnings.

 The playard, including side rails, must be fully erected prior to use.

Make sure latches are secure.

• Discontinue use of the product when child is able to climb out or has reached the height of 35 in. (890 mm), or 30lbs. (13.6kg)

 When child is able to pull to standing position, remove bumper pads, large toys and other objects that could serve as steps for climbing out.

 ALWAYS provide the supervision necessary for the continued safety of your child. When used for playing, never leave child unattended. Child in crib must be under supervision at all times.

 ALWAYS ensure that the playard, changing table, and the Rock-A-Bye Bassinet are safe by checking regularly, before placing the child in it, check that every part is properly secured in place.

NEVER leave the Bassinet in place when child is in playard.

 NEVER leave Changing Table in place when child is in the playard.

 NEVER leave Rock-A-Bye Bassinet in place when child is in the playard. Only one child can use the Playard/Nursery Center at any time.

 NEVER use this product if there are any loose or missing fasteners, loose joints, broken parts, or torn mesh/fabric. Check before assembly and periodically during use.

This product is not intended for commercial use.

AVERTISSEMENT

IMPORTANT! To ensure safe operation of your playard, please follow these instructions carefully. Please keep these instructions for future reference.

IMPORTANT! Before assembly and each use, inspect this product for damaged hardware, loose joints, missing parts or sharp edges. NEVER use if any parts are missing or broken.

IMPORTANT! Adult assembly is required.

MAINTENANCE

MAINTENANCE AND CLEANING INSTRUCTIONS:

Use only household mild soap and warm water.

DO NOT USE BLEACH. DO NOT MACHINE WASH.

PARTS


Check the parts list on the back cover to make sure you have all the parts for this model before assembling the playard.




Playard



Mattress




Travel / Storage Bag




(2) Short Bar with Connectors



(2) Curved Connector Bar



Large bassinet with metal support tubes




Changing Table




* Parent Organizer



*Music Center



(2) or (4) Rock-a-Bye bassinet Bars



**Portable Rock-a-Bye bassinet

ASSEMBLY

TO ASSEMBLE PLAYARD



ATTENTION: Playard must be fully assembled and securely locked before installing or using other accessories.

 Unzip bag and remove Playard frame (Fig. 1). Undo the Fasten straps and set the Mattress aside.

 No. No. 1

DO NOT push center down yet.




Fig. 1



Fig. 2


2) • Top rails must be fully locked before lowering center. Pull up one rail at a time, hold one hand on each side of the rail and pull up sharply, do not pull from the middle where the center latch release is located, make sure both tubes latch in place and each rail is rigid (Fig. 2).
IMPORTANT: The center must be raised while locking the rails. If one rail will lock but the other side will not then, unlock the rail by squeezing the release in the center and try again.



ASSEMBLY ASA

3) • Once all four (4) top rails are locked in place, push down on the center handle (Fig. 3a). The center mechanism automatically locks in place.

IMPORTANT: Test each top rail by pushing down slightly to confirm each is rigid and securely in place before use (Fig. 3b).






ASSEMBLY

For already assembled Playard you may skip to page 19 for the accessories instructions. To install mattress into the playard proceed to Step 4.

4) • Place the Mattress on the floor of the Playard with the padded side facing up (Fig. 4).



5) • Insert the hook & loop fasteners located on the underside of the mattress through the slots in the floor of each end of the playard (Fig. 5a). Fasten the hook and loop fasteners to the underside of the playard floor to prevent the mattress from moving (Fig. 5b).
IMPORTANT: The handle located in the center of the Playard floor MUST remain raised (Approx. 45.7 cm or 18 inches) while locking the side rails in place. If the center is not raised the rails will NOT lock.

If you experience difficulty and one side of the rail will lock but the other side will not then, unlock the rail by squeezing the release in the center and try again.




Fig. 5a




Fig. 6

6) • To operate the brakes on the wheels, press downward on the brake levers. To release, lift upward on the lever (Fig. 6).

FOLDING PLAYARD

- 7) Release the hook and loop fastener holding the Mattress from underneath the Playard floor or the Bassinet and set the mattress aside. DO NOT unlock top rails yet, center of floor handle must be raised before top rails will unlock.
 - Rotate the center handle counter-clockwise 90 degrees and raise the center as high as the top rails (Fig. 7). Gather the Legs and Wheels together towards the center as close as possible so that they nearly touch.



Rotate before lifting

Fig. 7

8) • Locate the rail latch release in the center and bottom side of each rail. Squeeze the lever with two hands until the rail releases the two tubes (Fig. 8a), then push down (Fig. 8b). NOTE: If the top rail(s) do not release completely, DO NOT FORCE! Lift the center of floor higher. Both tubes must be released for the top rail to fold.




Fig. 8b

9) • Gather all four (4) corners and the center together tightly (Fig. 9). Wrap Mattress around Playard frame with padded side facing inward.



- 10) Secure the hook and loop fasteners by feeding them through the loops on the end of the mattress then fold them back onto themselves (Fig. 10).
 - Place folded Playard into carry bag so that the handle comes through the opening between each side of the zipper.



Fig. 10

⚠ WARNING

ACCESSORIES

Bassinet & Cradles Warnings:

WARNING: Failure to follow these warnings and the instructions could result in serious injury or death. WARNING FALL HAZARD: To help prevent falls, do not use this product when the infant begins to push up on hands and knees or has reached the height of 25 in. (635 mm), weight of 15 lbs. (6.8 kg), whichever comes first.

 ALWAYS check that the large bassinet is securely locked on the base/stand by pulling upwards on the large bassinet bed.

SUFFOCATION HAZARD Infants have suffocated:

- In gaps between extra padding and sides of bassinet/ cradle and
- On soft bedding Use only the pad provided by the manufacturer. NEVER add a pillow, comforter, or another mattress for padding.
- Always attach large bassinet securely. If the large bassinet is not secured, at all locations child could get neck trapped between large bassinet and playard frame.
- Do not place items with a string around a child's neck such as hood strings or pacifier cords. Strings can cause strangulation! Do not suspend strings over the large bassinet or attach strings to toys.
- NEVER use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.
- Use the large bassinet with only one child at a time.
- NEVER place a child under the large bassinet.

⚠ WARNING


- The Playard must be fully assembled and installed before using.
- The playard, including side rails, must be fully erected prior to use. Make sure each latch is secure.
- NEVER leave the large bassinet in place when child is in playard.
- NEVER place a child under the large bassinet.
- NEVER leave Changing Table in place when child is in the playard.
- NEVER leave the Rock-A-Bye Bassinet in place when child is in the playard. Only one child can use the Playard at any time.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their back to sleep, unless otherwise advised by your physician.
- ALWAYS place child on back to sleep.
- ALWAYS provide the supervision necessary for the continued safety of your child. NEVER leave children unattended.
- If a sheet is used with the mattress/pad, use only the one provided by Babyjoy or one specifically designed to fit the dimension of the playard mattress.
- Discontinue use of the large bassinet and the changing table when child begins to push up on hands and knees or has reached the height of 25 in. (635 mm), weight of 15 lbs. (6.8 kgs) or 3 months old, whichever comes first.
- Child can become entrapped and die when improvised netting or covers are placed on top of a playard. Never add such items to confine child in playard.

SUFFOCATION HAZARD: Infant carrier can roll over on soft surfaces and suffocate child. NEVER place carrier on beds, sofas, or other soft surfaces.

FALL HAZARD: ALWAYS check that the large bassinet is securely locked on the base/stand by pulling upwards on the large bassinet.

ASSEMBLY


TO ASSEMBLE LARGE BASSINET



Bassinet with metal support tubes

ATTENTION: Playard must be fully assembled and securely locked before installing or using the Bassinet feature (See To Assemble Playard section). You will need to remove the mattress from the bottom of the Playard to use inside your Bassinet.

- 11) Connect opposing Mattress Support Tubes that are attached to the bottom of the Bassinet (Fig. 11a).
 - Before placing the Mattress into the Bassinet, make sure Mattress Support tubes are connected (Fig. 11b).







Fig. 11b

12) • Position the Bassinet over and down into the fully assembled Playard. Secure in place by pushing down firmly on each plastic support clip until all are snapped into place (Fig. 12).



Fia. 12

13) • Place the Mattress into the Bassinet with the padded side facing upward (Fig. 13).




TO REMOVE LARGE BASSINET

 Remove Mattress from Bassinet. Disconnect opposing Mattress Support Tubes. Unsnap all clips and lift Bassinet.

TO ASSEMBLE CHANGING TABLE

ATTENTION: Playard and large bassinet must be fully assembled and securely locked before installing or using the changing table feature (See To Assemble Playard and large bassinet section

Changing Table Assembly will require the following parts:



ACCESSORIES


Changing Table:


- ⚠ WARNING FALL HAZARD: Children have suffered serious injuries after falling from changing tables. Falls can happen quickly.
- · STAY within arm's reach.
- ALWAYS secure the changing table to the playard frame. See instructions, see page 32-33 for details.



SUFFOCATION HAZARD: Babies have suffocated while sleeping on changing tables. Changing tables are not designed for safe sleep.

- NEVER allow baby to sleep on changing table.
- NEVER leave the changing table in place when the child is in the large bassinet or the playard. To prevent your child from falls and other injuries, always use the safety belt when children are on the changing table.
- Discontinue use of the large bassinet and the changing table when child begins to push up on hands and knees or has reached the height of 22 in. (558.8 mm), weight of 15 lbs. (6.8 kg) or 3 months old, whichever comes first.
- Do not use changing table if it is damaged or broken.
- ALWAYS use the restraint system. Adjust belt as needed to get a snug fit.
- 14) Lay the changing table cover on a flat surface with the back side facing up. Locate the 2 Curved Connector Bars (Fig. 14a). Insert the Curved Connector Bars into the backside of the Changing Table covering (Fig. 14b).
 - Attach the Short Bars with the 2 Connectors to the Curved Connector Bars (Fig. 14c).
 Be sure the clips are faced up during this preparation on the backside of the changing table covering (Fig. 14d). Insert both ends with the push pins into the Curved Connector Bars. Ensure all pins click into postion on all 4 connection points (Fig. 14e).
 - Close the covering by using the hook and loop fasteners on the flap. Flip the flaps over the bars and fasten together (Fig.14f).





TO SECURE THE CHANGING TABLE TO THE PLAYARD

IMPORTANT! When the changing table is on the upper position the changing table must be secured to the playard frame by using the snap buttons straps or fasteners provided.

- **15)** Locate the 4 clip fasteners on the bottom of the changing table (Fig. 15a).
 - To attach the changing table to the playard, lower the changing table into the large bassinet. Push down on the 4 clips to secure the it onto the large bassinet railing (Fig. 15b). Secure the two snaps on the strap down onto the Playard (Fig. 15c).

NOTE: DO NOT use changing table on playard without the large bassinet (See To Assemble large bassinet section, pages 19 - 26) and securing the clips to playard.





Fig. 15a






Fig. 15b

Fig. 15c

TO USE CHANGING TABLE RESTRAINT SYSTEM

- 16) Place child on changing table, make sure hand and arms are clear of the restraint. Bring the restraint around the child's waist and clip the male and female ends of the buckle together (Fig. 16a).
 - Tighten strap until fits snug around child's waist (Fig. 16b).
 DO NOT OVER TIGHTEN.
 - To remove, unsnap the buckle.
 ATTENTION: NEVER use changing table if it is damaged or broken.




Fig. 16a

TO REMOVE CHANGING TABLE

17) • Unsnap from the playard (Fig. 17a). Locate all 4 clip/fasteners on the changing table. Pull up on all 4 clips to release them from the playard frame (Fig. 17b).





Fig. 16b






Fig. 17b


PARENT ORGANIZER ASSEMBLY



Parent Organizer

- 18) Parent Organizer: Position each hook so that the hooked end is facing the rear side of the organizer. Press the hook down firmly into the slot until it snaps into place (Fig. 18a). Diaper Stacker: Skip to step 18b.
 - Connect the Parent Organizer/Diaper Stacker to the Playard by sliding the two (2) connecting clips over an open portion of the top rail of the Playard (Fig. 18b).

NOTE: The Parent Organizer / Diaper Stacker can only be installed on open sides of the Playard where the connecting clips can easily be attached without interfering with other features.








Fig. 18b

⚠ WARNING

ACCESSORIES

Warnings for Toy Accessories including Toybar / Mobile / Canopy with toys:

⚠ WARNING:

- · Possible entanglement injury.
- · Keep out of baby's reach.

- Remove Toybar/Mobile/Canopy with toys when baby begins to push up on hands and knees. Recommended use from birth to 5 months.
- Toys are not intended to be mouthed by the baby and should be positioned clearly out of reach of the baby's face and mouth.
- ALWAYS attach all provided fasteners (strings, straps, clamps, etc.) tightly to playard according to these instructions. Check frequently.
- Do not add additional strings or straps to attach to any other crib or playpen.
- The Toybar/Mobile/Canopy with toys is intended for visual stimulation and not to be grasped by the child.

ASSEMBLY

TO ASSEMBLE PORTABLE ROCK-A-BYE BASSINET



⚠ WARNING

MARNING: Failure to follow these warnings and the instructions could result in serious injury or death.

FALL HAZARD: To prevent falls, stop

using the product when infant:

 Begins to wiggle out of position or turn over in the product, head touches the upper edge of the product, reached the height of 25 in. (635 mm), weight of 15 lbs.(6.8 kgs) (approximately 3 months of age).

ALWAYS use restraint system if a restraint system is

provided with the product.

fants have suffocated:

 In gaps between extra padding and sides of bassinet/ cradle and

 On soft bedding Use only the pad provided by the manufacturer. NEVER add a pillow, comforter, or another mattress for padding.

When trapped between product and adjacent

surfaces.

ONLY use ROCK-A-BYE BASSINET on playard when

it is securely attached.

• If a sheet is used with the pad, use only the one provided by Babyjoy or one specifically designed to fit the dimension of the ROCK-A-BYE BASSINET bassinet mattress.

NEVER use ROCK-A-BYE BASSINET in different

product.

NEVER leave child unattended.

SUFFOCATION HAZARD: Infant carrier can roll over on soft surfaces and suffocate child. NEVER place carrier on beds, sofas, or other soft surfaces.

△ WARNING

FALL HAZARD: Child's activity can move carrier. NEVER place carrier on counter tops, tables, or any other elevated surface.


NEVER use this carrier as a means to transport an infant in a motor vehicle. Infant carriers not intended for use as infant restraint devices in motor vehicles.

- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their back to sleep, unless otherwise advised by your physician.
- FALL HAZARD Always check that the Rock-A-Bye is securely locked on the base/stand by pulling upwards on the Rock-A-Bye bed.
- The playard, including side rails, must be fully erected prior to use. MAKE SURE EACH LATCH IS SECURE.
- Strings can cause strangulation! NEVER place items with a string around a child's neck such as hood strings or pacifier cords. NEVER suspend strings over Rock-A-Bye bassinet or attach strings to toys.
- WARNING: Possible entanglement injury with toys attached. Keep out of baby's reach.
- Do not use Rock-A-Bye bassinet or place on playard when baby begins to push up on hands and knees.
- NEVER place product near a window where cords from blinds or drapes can strangle a child.
- Always provide the supervision necessary for the continued safety of your child.
 NEVER leave child unattended.
- **NEVER** use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.
- Use Rock-A-Bye bassinet with only one child at a time.
- DO NOT use large bassinet when using Portable Rock-A-Bye Bassinet.
- NEVER place a child under the Rock-A-Bye bassinet.
- **NEVER** store the Rock-A-Bye bassinet in the playard while in use.
- The large bassinet must be fully assembled and installed before using.
- To help prevent heat build-up inside the playard and to avoid overheating your child, when using the Rock-A-Bye Bassinet NEVER use an outdoor canopy.
- NEVER leave Portable Rock-A-Bye Bassinet in place when child is in the playard.
 Only one child can use the Playard at any time.
- **ALWAYS** ensure that the playard, changing table, and Portable Rock-A-Bye Bassinet are safe by checking regularly, before placing the child in it, that every part is properly and securely in place.
- NEVER use this product if there are any loose or missing fasteners, loose joints, broken parts, or torn mesh/fabric. Check before assembly and periodically during use.

ASSEMBLY

ATTENTION: Playard and large bassinet must be fully assembled and securely locked before installing or using the Portable Rock-a-Bye bassinet feature. (See To Assemble Playard and large bassinet sections, pages 19 - 26).

Rock-A-Bye Bassinet assembly will require the following parts:



(2) Rock-a-Bye bassinet Bars



Portable Rock-a-Bye bassinet

19) • Put the Bassinet on a flat surface with the Carry handle on the underside (Fig. 19a). Pull the flaps of the fabric over the Bar housing as shown in the diagram (Fig. 19b).

NOTE: Ensure that the fabric opening wraps completely around the Bar housing.

• Use the the hook and loop fasteners to close the flap (Fig. 19c). Repeat on the opposite side.




Fig. 19b







Fig. 19a



- **20)** To insert the Rock-A-Bye Bassinet Bars: Open the 4 foot extensions on both Bars (Fig. 20a). Before inserting them into the housing check that the foot extensions all point inward as seen in the diagram (Fig. 20b).
 - Insert the Bars into the housing by aligning the push pin with the hole (Fig. 20c). Ensure that the pins click into position (Fig. 20d).
 NOTE: Look closely at the pin hole to be sure the push pin has completely come out of the hole. Repeat for all 4 connection points.













Fig. 20b

 Rotate the entire Rock-A-Bye and stand it on the foot extensions (Fig. 20e).







CANOPY / CARRY HANDLE




Fig. 20e

21) • The rear of the canopy has 2 fabric openings. Pull both opening over the 2 clips at the rear of the bassinet frame. Ensure to wrap the elastic completely over the bassinet frame (Fig. 21a).
NOTE: Always complete the canopy before attaching the bassinet to the playard frame.



Fig. 21a

• To raise the handle, push both buttons on each side of the handle with your fingers while pulling it forward (Fig. 21b).




Fig. 21b

 To lower handle, push both buttons on each side of the handle with your fingers while pushing the handle backwards (Fig. 21c).




Fig. 21c

ROCKER FUNCTION

22) • Turn the bassinet over and close the 4 peg legs (Fig. 22a). Set Bassinet on a flat surface (Fig. 22b).

NOTE: Rocking requires adult assistance and supervision, this is not an automatic rocking cradle (Fig. 22c).

NEVER use Bassinet on raised surface

such as Table, Bed or Chair. A fall can occur.




Fig. 22a




Fig. 22b




Fig. 22c


TO SECURE THE PORTABLE ROCK-A-BYE BASSINET TO THE PLAYARD


IMPORTANT! When the Rock-A-Bye Bassinet is on the upper position, it must be secured to the playard frame by using the snap buttons, straps, or fasteners provided.

- 23) Locate the 4 clip fasteners on the bottom of the Rock-A-Bye Bassinet (Fig. 23a).
 - To attach the Rock-A-Bye Bassinet to the Playard, lower it into the large bassinet.
 Push down on the 4 clips and secure it onto the large bassinet railing (Fig. 23b). Secure the two snaps on the strap down onto the Playard (Fig. 23c).

ATTENTION: Playard and large bassinet must be fully assembled and securely locked before installing or using the Portable Rocka-Bye bassinet feature. (See To Assemble Playard and large bassinet sections, pages 9 - 26).







 Reverse the step above to remove the Rock-A-Bye Bassinet.

TO FOLD REMOVABLE ROCK-A-BYE BASSINET

WARNING: Care must be taken when folding and unfolding to prevent finger entrapment.

CAUTION: Do not allow children near while folding and unfolding.

- 24) Remove the Rock-A-Bye Bassinet from the Playard and place on a flat surface (Fig. 24).
 - To Fold Reverse the previous section: TO ASSEMBLE Portable Rock-A-Bye Bassinet on pages 49 - 53.




Fig. 24

OPERATION

MUSIC CENTER



⚠ WARNING: Keep batteries out of children's reach. Old and new batteries should not be mixed. Alkaline, standard carbon-zinc, and rechargeable nickel-cadium batteries should not be mixed. Remove batteries before storing music center for a long period of time.

25) • The Music Center is designed to be attached to the playard's/bassinet's long rail (Fig 25).




Fig. 25

Music Operation

26) • The Music Center requires 4 AA batteries. Please see figure 26 for battery installation. Unscrew the battery door screws and pull outward on the battery door. Install batteries as shown. Re-install battery door and secure with screws.




Fig. 25





Fig. 26





MUSIC

To listen to NATURE sounds, press the NATURE button. Press the button to change the sound.

NATURE SOUNDS

To listen to SLEEP music, press the SLEEP button. Press the button to change the song.

SLEEP MUSIC

These 2 buttons control the unit's volume.

VOLUME CONTROL

1

➤ VIBRATION: To use the VIBRATION, press down VIBRATION button once to activate the speed, press again for faster speed. Press it again to reduce the speed.



NIGHT LIGHT: To use the night light, press the NIGHT LIGHT button.



OTHER

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1 this device may not cause harmful interference, and

2 this device must accept any interference received, including interference that may cause undesired operation.

⚠ WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★ ★ ★ ★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

