




COSTWAY®

**Please give us a chance to make it right and do better !**

Contact our friendly customer service department for help first.  
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana    UK office: Ipswich    AU office: Truganina



## Contact Us !

**Do NOT return this item.**

Contact our friendly customer service department for help first.



US:cs.us@costway.com  
UK:cs.uk@costway.com  
AU:cs.au@costway.com

## USER'S MANUAL

### Baby Playpen Crib BB5559/BB5576

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



## Before You Start

Please read all instructions carefully and keep it for future reference.

### General Warnings:

- ⚠ Attention: To prevent possible injury by entanglement, remove this toy when the child starts trying to get up on its hands and knees in a crawling position.
- ⚠ Danger! Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.
- ⚠ The product must be installed and used under the supervision of an adult.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ Remove all Packaging, separate and count all parts and hardware before installation.
- ⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- ⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.

## ➤ Manual Instruction

**IMPORTANT:** Read all instructions BEFORE assembly and USE of product, and KEEP THEM FOR FUTURE USE.



### 1 WARNING

WARNING: Never leave the child unattended.

WARNING: Do not put the playpen near a fireplace or any other source of heat.

WARNING: Upper age /weight limit for children using the playpen: 3 years or 15kgs/33lbs.

WARNING: Do not use the playpen without the bottom being in place.

WARNING: Make sure the playpen is completely unfolded and all the locking system are fully secured before putting your child into it.

### 2. RECOMMENDATIONS

RECOMMENDATION: Check that all assembly mechanisms are properly secured and regularly monitored.

RECOMMENDATION: To avoid injury, keep children well away when folding or unfolding the playpen.

RECOMMENDATION: Do not leave anything inside the playpen and do not place it alongside anything that the child could climb onto or which could pose a risk of suffocation or strangulation, e.g. strings, curtains, ties, etc.

RECOMMENDATION: Do not move the playpen when the child is in it.

RECOMMENDATION: Do not use if one or more items are broken or missing.


RECOMMENDATION: Use only accessories or spare parts that have been approved by the manufacturer.

RECOMMENDATION: Make sure that your child cannot climb out of the playpen. To avoid the risk of falls, stop using the playpen as soon as the child is able to climb out of it.


## > LIST OF PARTS

Check that no parts are missing before setting up the playpen.


- A. 1 playpen
- B. 1 carrying bag
- C. 1 foldable mattress
- D. 1 diaper changer
- E. 1 toy bar
- F. 1 second level



A. playpen



B. carrying bag




C. foldable mattress



D. diaper changer





E. toy bar



F. second level

## > ASSEMBLY INSTRUCTIONS




### STEP 1: OPENING OF THE PACK

Open the carrying bag (Fig.1) and take the playpen out. Detach the foldable mattress from the playpen by unfastening the self-fastening straps (Fig. 2) to release the playpen.

### STEP 2: SECURING THE PLAYPEN




a. Unfold the structure slightly to push the sides of the playpen apart (Fig. 3).




### IMPORTANT

**Start by unfolding the playpen by pushing the sides apart. The bottom of the playpen( in the centre) should be lowered last.**

b. Follow the instructions illustrated Fig.4a and Fig.4b on both sides at the same time.






c. Finish by banging down on the bottom of the playpen( Fig .5) to secure the blocking mechanism.





### STEP 3: INSTALLATION OF SAFETY BUCKLE FOR SECOND LEVEL

Before installing, remove the foldable mattress from the bottom of playard, place bassinet inside of the playard and attach the 12 clips to the top rails (fig.6/fig.6-1/fig.6-2).



### STEP 4: Install the bassinet

a. Insert the metal tube together in the bottom of the playard as shown, MAKE SURE tubes are connected before installing the foldable mattress (fig.7-1/fig.7-2).




b. Slip the foldable mattress into the bottom of the playpen(fig.7-3).





### STEP 5: SECURE THE DIAPER CHANGER IN PLACE ON THE HANDRAIL

a.Fasten the diaper changer clip to the armrest (fig.8)





b.Fasten the toy bar to the armrest (fig. 9/ fig. 9-1)



## ➤ FOLDING AND STORING THE PRODUCT

### STEP 1: FOLDING THE PLAYPEN





a. Remove the mattress from the playpen (Fig. 10) and lift up the bottom with the help of the fabric pulling strap (Fig.10-1).



b. Lift up rims A simultaneously while pressing the unlocking button underneath the rim( Fig.11).

c. Lift up rims B simultaneously while pressing the unlocking button underneath the rim( Fig.12)

Each rim should buckle on both sides, as shown here(Fig. 13 and Fig.14).





### IMPORTANT

**If the rims of the playpen do not fold down completely, repeat the procedure shown in Fig.11**

### STEP 2: STORING THE PLAYPEN

Once the playpen locking mechanisms have been released, fold it up completely and fit the mattress around the structure, securing it with the self-fastening straps (Fig.15), Slip the whole thing into the carrying bag (Fig. 16).



### MAINTENANCE INSTRUCTIONS

You can extend the life of your playpen by taking good care of it, here is some advice.

1 - Never immerse the playpen, just wipe down the different surfaces.

2 - Clean with a sponge and soap or a gentle detergent. Air-dry, preferably away from sunlight.

3 - Always store this product in a well-aired place.

4 - Do not expose to sunlight for long periods of time.