





COSTWAY®



USER'S MANUAL Baby High Chair BB5517

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com











Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

Please read all instructions carefully and keep it for future reference.

General Security Warning

Caution: The Product is not suitable for the children under 3 years

Danger: Keep all small parts and packaging materials for this product away from babies and

children, otherwise they may pose a choking hazard.


Danger: Lack of attachment may cause a risk of tipping.



Warning for Assembly

- **⚠** Construction only by adults
- ⚠ Remove all Packaging, separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during construction, und place the product always on a flat, steady and stable surface.

The way to change high chair to small chair:




Chair part list:

Please check every part and follow up the assembling steps for complete baby high chair. Do not use the product if any part is broken or missing.

Part Photo	Part Name (Quantity)	Part Photo	Part Name (Quantity)
	Chair Seat (1 pc)		Tray (1 pc)
	Foot rest (1 pc)		Leg support (2 pcs)
	Upper Legs (4 pcs) Lower legs (4 pcs)	A B C E	Screw (5pcs) 4X47MM (A*2pcs) 5X42MM (B*2pcs) 5X12MM (C*1pc) Nuts (D*5pcs) Tool (1pc+1pc+1pc) Wooden baffle (1pc) Anti-slip pads for small chair (E*4pcs)

Installation:

- 1. Assemble the four (4) legs by joining the upper and lower legs according to the same marks (A+A, B+B, C+C, D+D). (Fig-1)
- 2. Screw the four (4) legs into the seat bottom. (Fig-2, Fig-3)



- 3. Install the two (2) leg supports and footrest by using screws 'A', 'B', 'C' and 'D' nuts. (Fig-4)
- a. Begin by joining the two (2) leg supports using screw 'C' and a nut through the center hole. The holes on the leg supports should extend downwards.
- b. Next, install the footrest onto the front side of chair. Screws 'A' (the two longer screws) needs to pass through the foot rest, then the chair leg and the leg support before securing with a nut.

The leg support with the "O" marking should be on the left-hand side. (Fig-5) Adjust the chair leg by twisting it to align hole for screw.

Finally, attach the leg supports to the back legs using screws 'B' (the two shorter screws) and remaining nuts.





- 4. Put the tray on the handrail. (Fig-6)
- 5. Press the tray to make sure it is securely locked in place. (Fig-7)
- 6. Make sure the seat cover is put in right place in seat. (Fig-6) Check high chair again to make sure everything is OK before use.





(Fig-7)





Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us!

We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be guite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE. GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

