




COSTWAY®

**Please give us a chance to make it right and do better !**

Contact our friendly customer service department for help first.  
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana    UK office: Ipswich    AU office: Truganina



## Contact Us !

**Do NOT return this item.**

Contact our friendly customer service department for help first.



US: [cs.us@costway.com](mailto:cs.us@costway.com)  
UK: [cs.uk@costway.com](mailto:cs.uk@costway.com)  
AU: [cs.au@costway.com](mailto:cs.au@costway.com)

## USER'S MANUAL

### Baby Playpen BS10009 / BS10010

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.




## Before You Start

Please read all instructions carefully and keep it for future reference.

### General Warnings:

- ⚠ Danger! Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.
- ⚠ The product must be installed and used under the supervision of an adult.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ Remove all Packaging, separate and count all parts and hardware before installation.
- ⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- ⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.

## Playpen Packing Accessories




Door Panel



Game Panel




Manual




Small Panel


## Precautions




Place on a flat, spacious floor.



Can not be placed in the sand surface, uneven ground




Can not be placed on a slope



Can not be placed in water or water seepage.


## Product Installation

1





Open the packing box and take out the folding fence.

2



Turn the positioning knob to adjust the shape of the fence, then turn the positioning knob to fix the position.

## Product Size



## Tips

1. This product is only for adult to assemble.
2. Place it on a flat and clean floor.
3. Use under adult supervision and climbing is prohibited.
4. Keep away from fire and power supply.
5. Make sure of a wide open site for installation.
6. Put the product in a well-lit room.
7. Do not put this product in water or near water seepage.
8. Can not be used upside down.
9. Check all the parts are well connected before use.
10. Packing materials are not toys, please keep them properly.
11. Clean the product regularly with sponge, soapy water or other non-corrosive liquids ensuring a healthy environment for baby.
12. Recommended for 3 months - 6 years.

## Baby playpen



**BS10010**

