






# **COSTWAY**®



### **USER'S MANUAL**

L - shaped desk HW63118

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

#### Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

**Follow Costway** 

Visit us: www.costway.com











**FLOOR AREA** 

2MX2M




## **Contact Us!**

#### Do NOT return this item.

Contact our friendly customer service department for help first.



## **Before You Start**




Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.

Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.

⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.


Keep the handtools close at hand. Do not use power tools to assemble your furniture.
They may scratch or damage the parts.








	BOX CONTENTS	
Вох	Specifications	Qty
A箱	2	1PC
	5	1PC
	6	1PC
	7	1PC
	8	1PC
	10	3PC
	11	1PC
	12	1PC
	13	1PC
	14	1PC
	15	1PC
	16	1PC
	19	1PC
	20	1PC
	21	1PC
	22	1PC
	23	1PC
	24	2PC
	25	1PC
	26	1PC
	27	1PC
	28	1PC
Box	Specifications	Qty
B箱 —	1	1PC
	3	1PC
	4	1PC
	9	2PC
	17	1PC
	18	1PC

2













## STEP 1



















STEP 6






## **STEP 7**








#### PRODUCT ASSEMBLY

## STEP 8











## **STEP 11**








PRODUCT ASSEMBLY

## **STEP 12**














B x 3











14







16


#### PRODUCT ASSEMBLY



Ax4







## **Care and Maintenance**

Use a soft, clean cloth that will not scratch the surface when dusting. Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area. Using solvents of any kind on your furniture may damage the finish. Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

## Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading,

warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.

20



#### Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

**US office: Fontana, California** 

**UK office: Ipswich** 



- \* Reward Points
- \* Exclusive Customer Service
- \* Personalized Recommendations
- \* Permanent Shopping Cart
- \* Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

