



TIPS:

Your suggestions and comments for Costway are really important to us!
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2018

Great product so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, Costway will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!



COSTWAY

WHERE THERE IS COSTWAY THERE IS HOME



USER'S MANUAL

Christmas Tree

CM22794

GB

ARTIFICIAL CHRISTMAS TREE
READ CAREFULLY, KEEP FOR FURTHER REFERENCE

Article of decoration
For indoor use only
All the diagrams are given for illustrative purposes only. There may be variations from one model to another.


Content :

Reference*	Height	Number of tree parts	Base
CM22794	4FT	1	Decorative plastic urn


* The reference number is indicated on the carton above the gencod.
No tools are required for the assembly.

Assembly instructions


1 - Gently lower branches into proper position(Figure 1). Each Branch must be shaped to a natural position by spreading out the left and right tips away from the center tip. Continue to lower branches on upper section(s) in the same manner making sure not to place undue pressure on the brackets.



2 - Unfold one by one the branches beginning by the lower branches.



3 - Make final adjustment and trimming of the tree.



The tree is now ready to be decorated. Ensure that the decorations are uniformly distributed evenly on the tree.

Disassembly and storage

Remove all decorations.

Disassemble the tree in reverse order of the assembly.

For a better conservation, store the tree in its carton box in a cool dry place. Do not store when humid.

Caution

To be assembled by or under supervision of an adult.

Keep plastic bags out of reach of young children.

Keep away from fire or hot temperature. Do not light a candle on or near the tree. Do not leave lighted lighting chains unattended.

Do not overload the tree with heavy and/or too numerous decorations.

Place the tree on a plane surface in order to ensure its stability.

This tree is intended for indoor use only.

Keep an eye on young children.

Keep those information for future reference.

Made in China