






COSTWAY®



USER'S MANUAL Ultrasonic Humidifier EP24532US

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com









Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

A	Please	read	all	instructions	carefull	v
$\angle! \lambda$	riease	reau	all	IIISHUCHOIIS	Careiu	ш

🔨 Retain instructions for future reference.

⚠ Seperate and count all parts and hardware.

riangle Read through each step carefully and follow the proper order.

We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

Always place the product on a flat, steady and stable surface.

Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.


Ultrasonic Humidifier EP24532US Ratings:120V~, 60Hz, 28W

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed. Failure to follow these safety precautions may result in personal injury, property damage, fire or shock.

- 1. Read all instructions prior to use.
- 2. Always place unit on a flat, level surface AWAY from direct sunlight or computers or other sensitive electronic equipment. A waterproof pan, tray, mat or drop cloth is recommended: exposure to excess water or moisture can cause damage to some surfaces.
- 3. DO NOT place the appliance near heating devices. Keep cord away from heavy traffic areas and DO NOT place cord under rugs or allow cord to hang over a countertop or table where it can be pulled on or tripped over.
- 4. NEVER place a vaporizer where it is accessible to children.
- 5. CAUTION:To reduce risk of burns, supervision is recommended when a vaporizer is used near children, invalids or pets.
- 6. Position the unit so mist stream is aimed away from children, walls and furniture.
- 7. DO NOT use outdoors.
- 8. Use only 230V AC outlet. Be sure unit is plugged in firmly and completely. As with any electrical device, plug and unplug unit with dry hands only.
- 9. To avoid the risk of fire, shock or personal injury, do not use an extension cord. WARNING: Never operate unit with a damaged cord or plug.
- 10. Fill water container to the bottom of the fill line. DO NOT OVERFILL. DO NOT block moisture outlet. This will damage the vaporizer.
- 11. DO NOT add medication of any type into the moisture outlet or water container. Do not cover or place anything over any opening. Never drop or insert any object into any openings.
- 12. Turn the vaporizer off by unplugging the unit when not in use, before moving, filling or cleaning. NEVER tilt, move or attempt to empty the tank while unit is operating. Wait 15 minutes (or until cool) after unit is turned off and unplugged before attempting to refill water tank.
- 13. DO NOT touch unit or steam vapor during use. Steam is hot and burns can occur.
- 14. Use this appliance only for its intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons and property damage.
- 15. DANGER: To guard against electric shock, NEVER immerse the vaporizer head (upper housing) in water or other liquids.
- 16. Regular cleaning of the unit is needed. Please refer to the CLEANING section in this manual.
- 17. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 18. Children should be supervised to ensure that they do not play with the appliance.
- 19. This appliance is intended to be used in household and similar applications such as:
- Staff kitchen areas in shops, offices and other working environments;
- Farm houses:
- By clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments.
- 20. Save these instructions.

KNOW YOUR HUMIDIFIER



SETUP

Always unplug unit before filling with water.

Do not turn water tank upside down when full.

- 1. Place water tank securely on base, being sure it sits completely flat.
- 2. Open water fill lid and screw in ceramic water filter until locked.
- 3. Fill water tank approximately 1 inch below top of tank. Tank holds approximately 1.7 gallons of water.
- 4. Close water fill lid so it sits flat on top of tank.

OPERATING INSTRUCTIONS

- 1. Plug unit into power outlet.
- 2. Choose and install the short nozzle or the tall telescoping nozzle. Note: If using the telescoping nozzle, you can choose from 3 different

heights, depending on placement of unit.

- 3. Press ON/OFF button to turn on the unit.
- 4. Press the Mist level button to set your desired level of mist output. You can choose from 5 settings, indicated on display.

Note: If water level drops below requirement, red low water indicator will turn on. Follow instructions listed in setup section to refill.

5. When done, press ON/OFF button to turn off unit.

SETTING THE TIMER

Timer feature allows the unit to power off after a set amount of time. You can choose any amount of hours between 1-24 hours.

- 1. After unit turned on, press the timer button.
- 2. Continuously press the timer button until desired hours before shutoff is reached. Hours will display on the bottom left side of the screen.
- 3. Unit will power off after set time.
- 4. To re-start humidifier press ON/OFF button.

MUTE SOUND/DIMMING FEATURE

This mode allows for discrete sound and display operation.

- 1. Press the Sound/Dim button once to mute beep after button presses.
- Note: The dim display indicator will remain lit.
- 2. Press the Sound/Dim button twice to dim display and mute beep after button presses.

Note: The dim display indicator will remain lit.

3. Press the Sound/Dim button for a third time to restore sound and display.

CLEANING AND MAINTENANCE

Always turn off&unplug unit before cleaning.

We recommend cleaning the base, tank, filter and nozzles weekly to maintain optimal usage.

- 1. Unplug unit from power outlet.
- 2. Remove nozzles from water tank, remove water tank from base.
- 3. Empty water tank by turning upside down over.
- 4. Rinse tank with warm water several times.
- 5. Wipe the tank and base with soft cloth.
- 6. Clean and dry unit thoroughly prior to storage. Always store the unit in a cool, dry place until next use.

Ceramic filter cleaning

- 1. Unplug unit from power outlet.
- 2. Open water fill lid and find ceramic filter.
- 3. Turn the ceramic filter counter-clockwise until loose and remove.
- 4. Rinse the filter under running water for approximately 30 seconds.
- 5. Replace filter in unit and tighten by turning clockwise.

ENVIRONMENT FRIENDLY DISPOSAL



You can help protect the environment! Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal center.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE. GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

