


PATIOJOY



USER'S MANUAL


3 Pcs Wicker Set HW64402

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP!

**FLOOR AREA
2MX2M**



ASSEMBLED BY 2 ADULTS


Contact Us!

Do NOT return this item.


Contact our friendly customer service department for help first.



Before You Start




- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.




Board Identification


Not actual size




Left Arm x 2




Right Arm x 2




Back x 2



Seat x 2




Seat Cushion x 2



Back Cushion x 2


Board Identification

Not actual size




Hardware List

Actual size




M6 x 15mm

BOLT




M6 x 25mm

BOLT




M6 x 35mm

BOLT




M6

WASHER



ADJUSTABLE
LEVELLERS



4 x 4


ALLEN WRENCH

STEP 1

Insert adjustable levellers (M) to bottom of each Arm(A) by turning clockwise until secure.

Adjust height as desired.


Repeat step for the other side arm(B).



STEP 2


Attach the seat(D) to the arm (B) by inserting bolts (H & I) with washers (K) through the pre-drilled holes on the seat into the pre-welded nuts on the arm. Repeat step for the other side arm(A).

IMPORTANT: Do not tighten completely until assembly is completed.




STEP 3

Attached the back(C) to the seat (D) by inserting bolts(I) with washers (K).




STEP 4

Attached the back(C) to the arm (A&B) by inserting bolts (G) with washers (K).




STEP 5

Tighten all the bolts with the allen wrench,
and turn the chair to the upright position.
place the cushions(O&N) onto the chair seat.
Your chair is now ready for use.



Maximum Loads



⚠ WARNING

This item is only suitable within the specified maximum load-bearing. Heavier loads than the indicated load capacity may cause instability, resulting in possible injuries.

Board Identification

Not actual size




Table Top x 1





Table Leg x 2


Board Identification

Not actual size




Hardware List


Actual size




BOLT



BOLT




WASHER



ALLEN WRENCH


STEP 1

Attached the Table Leg(F) to the Table Top (E) by inserting bolts (J&G) with washers (K).




STEP 2

Tighten all the bolts with the allen wrench,
and turn the table to the upright position.
Your coffee table is now ready for use.



Maximum Loads



⚠ WARNING

This item is only suitable within the specified maximum load-bearing. Heavier loads than the indicated load capacity may cause instability, resulting in possible injuries.

Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since Long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.



