




**Please give us a chance to make it right and do better !**

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana      UK office: Ipswich



**COSTWAY®**

# Contact Us !

**Do NOT return this item.**

Contact our friendly customer service department for help first.



US:cs.us@costway.com  
UK:cs.uk@costway.com




**USER'S MANUAL**  
**Farmhouse Entertainment**  
**HW65216**

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.






## Before You Start




















- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



★ Hardware inside





<div>1</div> <div>x6</div> <div></div> <div>Ø15 x 23mm</div>	<div>2</div> <div>x8</div> <div></div> <div>M3.5 x 12mm</div>	<div>3</div> <div>x28</div> <div></div> <div>Dia 15mm 12mm</div>	<div>4</div> <div>x28</div> <div></div> <div>M6.5 x 32mm</div>
<div>5</div> <div>x39</div> <div></div> <div>Dia 6 x 30mm</div>	<div>6</div> <div>x4</div> <div></div> <div>M8 x 38mm</div>	<div>7</div> <div>x4</div> <div></div> <div>M4 x 20mm</div>	<div>8</div> <div>x12</div> <div></div> <div>BACKPLY STOPPER</div>
<div>9</div> <div>x12</div> <div></div> <div>M3 x 20mm</div>	<div>10</div> <div>x2</div> <div></div> <div>HANDLE</div>	<div>11</div> <div>x2</div> <div></div> <div>Glue 10cc</div>	<div>12</div> <div>x24</div> <div></div> <div>Dia 5 x 16mm</div>
<div>13</div> <div>x4</div> <div></div> <div>DOOR HOLDER</div>	<div>14</div> <div>x8</div> <div></div> <div>MDF SUPPORT</div>	<div>15</div> <div>x1</div> <div></div> <div>ALUMINIUM STRIP 1084mm</div>	<div>16</div> <div>x2</div> <div></div> <div>ANTI TIP STRAP</div>
<div>17</div> <div>x5</div> <div></div> <div>Dia 1/4 x 25mm</div>	<div>18</div> <div>x8</div> <div></div> <div>Dia 1/4 x 12mm</div>	<div>19</div> <div>x4</div> <div></div> <div>PULLEY</div>	

# Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

## Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.



It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and clearing at home will extend the life of your purchase.




Following these important and helpful tips will enhance your furniture as it ages.

1


( x2 )




( x1 )




2



3



27




HARDWARE LIST


Anti-Tip Strap - 2pcs  
M3.5 x 16MM - 2pcs

NOTE : Wall fixings are not supplied with this product as different wall materials require different types of fixing devices (such as Rawl plugs on brick work). You must use fixing devices suitable for the type of wall you intend to mount this product to. Please ensure that the head of any screw used has a diameter greater than the diameter of the mounting hole on the bracket and that the fixing is safe and secure before use.  
The screw supplied is to fix the anti-tip strap to the cabinet.

4




25




NOTE : THE MAXIMUM WEIGHT ON TOP PANEL UP TO 35KGS / 5KGS MAX WEIGHT PER SHELF .




26




5



6




7




- (14) x2  
MDF SUPPORT
- (4) x2  
M6.5 x 32mm

8




- (14) x2  
MDF SUPPORT
- (4) x2  
M6.5 x 32mm


23



24






- (9) x12  
M3 x 20mm
- (8) x12  
BACK PANEL STOPPER





22




- 2 x4 M3.5 x 12mm
- 13 x2 DOOR HOLDER



- 18 x4 Dia 1/4 x 12mm
- 19 x2 PULLEY
- 10 x1 HANDLE
- 7 x2 M4 x 20mm



9

(x2)




- 4 x4 M6.5 x 32mm
- 5 x8 Dia 6 x 30mm
- 11 x1 Glue 10cc

10




- 3 x4 Dia 15mm








11











21




12







15



16



17



18

