

Assemble Instruction

Attention : Do not tighten the screws until you have complete setup assembly.

5L-612

- ① 6pcs ② 4pcs ③ 4pcs

- ④ 2pcs ⑤ 4pcs ⑥ 14pcs

- ⑦ 7pcs ⑧ 2pcs ⑨ 2pcs ⑩ 1pc

A 1pc

B 1pc

C 1pc

D 1pc

E 1pc

F 2pcs

G 1pc

H 3pcs

J 2pcs

L 2pcs

I 3pcs

K 2pcs

M 2pcs

