




COSTWAY®

Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich AU office: Truganina



Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US: cs.us@costway.com
UK: cs.uk@costway.com
AU: cs.au@costway.com

USER'S MANUAL




2 PCS COS-LINDA BAR CHAIRS HW65790

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.




MODEL : COS-LINDA BAR CHAIRS


Important Note:

- Place all wooden parts on a clean and smooth surface such as rug or carpet to avoid the part from being scratched.
- Please follow the assembly instruction step by step.
- Do not tighten all screws until the chair is fully set-up.


PART LIST




1. CHAIR BACK X 2 pcs




2. FRONT LEG X 4pcs



3. CHAIR SEAT X 2 pcs



4. STRETCHER LEFT X 2 pcs



5. STRETCHER RIGHT X 2 pcs




6. STRETCHER FRONT X 2 pcs

HARDWARE LIST

A JCBC
M6 x 80 mm  8 pcs

B JCBC
M6 x 60mm  8 pcs

C JCBC
M6 x 45mm  4 pcs


D SPRING WASHER
M6  20 pcs

E FLAT WASHER
M6  20 pcs

F C/B SCREW
M4 x 32mm  12 pcs

G ALLEN KEY
M4  1 pc

STRETCHER



The Small Hole is for ' Marking " purpose to differential the Stretcher 'Left'

DIFFERENTIAL OF LEFT AND RIGHT BASEDION
WHILE YOU SIT ON THE CHAIR



FRONT LEG




Sticker (L) and (R) were pasted on the front legs.
R = Right
L = Left

STEP 1

STRETCHER FRONT
IS MORE SHORTER
COMPARED WITH
LEFT AND RIGHT

**STEP 2****STEP 3**

COMPLETED
ASSEMBLY

**Care and Maintenance**

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment.

Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.