




Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich



COSTWAY®

Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US:cs.us@costway.com
UK:cs.uk@costway.com

USER'S MANUAL




**TV STAND
HW66165**

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.




Before You Start

- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



★ Hardware inside



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care



It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.



Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.



18

















19




NOTE : THE MAXIMUM WEIGHT ON PANEL UP TO 40KGS / 5KGS MAX WEIGHT FOR DRAWER, 5KGS FOR PANEL.




(x2)
03

1	x16		Dia 15mm 12mm
2	x4		Dia 15mm 9mm
3	x20		M6.5 x 32mm
4	x44		Dia 6 x 30mm
5	x2		Glue 10cc
6	x12		M8 x 38mm
7	x12		M5 x 30mm
8	x2		HANDLE
9	x12		M3.5 x 25mm
10	x2		M4 x 19mm
11	x6		M3 x 16mm
12	x6		LEG
13	x6		FOOT
14	x8		Ø27mm


16




(x2)



17







14




- 9 x12
M3.5 x 25mm
- 4 x8
Dia 6 x 30mm


1




15




- 5 x2
Glue 10cc
- 4 x24
Dia 6 x 30mm




2




3





12





13





10





11




4




5




6



8



7



9

