




COSTWAY®

**Please give us a chance to make it right and do better !**

Contact our friendly customer service department for help first.  
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana    UK office: Ipswich    AU office: Truganina



## Contact Us !

**Do NOT return this item.**

Contact our friendly customer service department for help first.



US:cs.us@costway.com  
UK:cs.uk@costway.com  
AU:cs.au@costway.com

## USER'S MANUAL








### 5-Piece Patio Furniture Set HW69537

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



## Before You Start

- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



### Notice:

1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screws with tools gradually.
4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
6. Note: If one or several screws are fully tightened during assembly, there is a chance that the other screws will not align with the holes. However, all holes are designed to be larger to provide more room for screw adjustment.

(A) x2




Right frame

(B) x2




Left frame

(C) x2




Seat frame

(D) x2




Back frame

(E) x2



Seat cushion

(F) x2



Back cushion

(G) x2




Table leg frame

(H) x1






Table bottom frame

(I) x1




Wooden table top

(J) x4




Leg frame

(K) x2



Seat frame

(L) x2



Seat cushion

(1) x8



Bolt M6x40 mm

(2) x14



Bolt M6x35 mm

(3) x20



Bolt M6x25 mm

(4) x4



Bolt M6 x 20mm

(5) x46



M6x 1 Washers

(6) x4



Screw M6x25mm

(7) x4



Screw M6x15mm

(8) x2




Allen key M4

### Step 01



( 2x Chair assembly )

Connect Back frame (D) & Seat frame (C) with Bolt (2) & Washer (5)



**Step 02**


Connect part from Step 1 & Right arm (A) with Bolt (1), Bolt (2), Bolt (3) & Washers (5).

**Step 03**



Connect part from Step 2 & Left arm (B) with Bolt (1), Bolt (2), Bolt (3) & Washers (5).

**Step 04**

Put on Seat cushion (E) and Back cushion (F) to complete single chair.

**Step 05**


( 2x Ottoman assembly )  
Connect Leg frame (J) & Seat frame (K) with Bolt (2), Bolt (3) & Washer (5).

**Step 06**

Connect part from Step 5 & Leg frame (J) with Bolt(2), Bolt (3) & Washers (5).

**Step 07**



Put on Seat cushion (L) to complete the ottoman bench.



**Step 08**

( Table assembly )



Connect table leg frame (G) & Table bottom frame (H) with Bolt (3), Bolt (4) & Washers (5).

**Step 09**

Connect part from step 8 & Wooden table top (I) with Screw (6) and Screw (7).

**Step 10**

Complete the Table.

**Finished**

## Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

## Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.