




3 Pieces Wicker Bistro Set  
**HW70703**



## Before You Start


- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.






1 x2

Side panel




2 x1

Shelf panel




3 x2

Table leg 1




4 x2

Table leg 2




5 x1

Table top




6 x2

Right leg frame




7 x2

Left leg frame




8 x2

Backrest




9 x2

Seat




10 x2

Seat Cushion



11 x2

Back Cushion




Ⓐ x4

M6x15mm  
Bolt




Ⓑ x4

M6x25mm  
Screw




Ⓒ x8

M6x35mm  
Bolt



Ⓓ x8

M6x50mm  
Screw



Ⓔ x20



M6x40mm  
Screw





Ⓕ x2

Allen key



1





2





3





4



**5** x2





**6** x2







**7** x2




**8** x2




---

## OPTION 1



---

## OPTION 2





## Return / Damage Claim Instructions

- ⚠ **DO NOT discard the box / original packaging.**  
In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
- ⚠ **Take a photo of the box markings.**  
A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
- ⚠ **Take a photo of the damaged part (if applicable).**  
A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
- ⚠ **Send us an email with the images requested.**  
Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.

**USA** office: Fontana

**GBR** office: Ipswich

**AUS** office: Truganina

If you're having difficulty, our friendly  
customer team is always here to help.



USA: [cs.us@costway.com](mailto:cs.us@costway.com)  
AUS: [cs.au@costway.com](mailto:cs.au@costway.com)  
GBR: [cs.uk@costway.com](mailto:cs.uk@costway.com)