



**COSTWAY**  
WHERE THERE IS COSTWAY THERE IS HOME



**USER'S MANUAL**

**DOG HOUSE**

**PS7391**



**TIPS:**

Your suggestions and comments for Costway are really important to us!  
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far  
February 24, 2018  
Great product so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, Costway will be more consistent to offer you  
**EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!**

US office:Fontana  
UK office:Ipswich




**COSTWAY**  
WHERE THERE IS COSTWAY THERE IS HOME




PS7391 Wooden Dog House

PRODUCT ASSEMBLY


**INSTRUCTIONS FOR DOGHOUSE**




**Step 1:** Using 6 big screws, screw the parapet a, b, c, d together.




**Step 2:** Using 5 small screws, screw the all parapets to the top.



**Step 3:** Using 4 big screws, screw the 2 side panels to the top.




**Step 4:** Place the shell on the bottom.




PS7391 Wooden Dog House

PRODUCT ASSEMBLY


**INSTRUCTIONS FOR DOGHOUSE**



**Step 5:** Using 8 big screws, screw the front panel and the back panel to the two side panels.



**Step 6:** Using 12 small screws, screw the 2 banisters and 3 steps.



**Step 7:** Using 3 small screws, screw the stair to the doghouse.

