


# Tool Chest and Cabinet Assembly Instructions


1. Insert caster into caster assembly holes, as shown on illustration



If caster assembly fits loose, using a screwdriver, slightly spread apart split bearing on shaft. If caster is difficult to insert, crimp split bearing slightly with pliers. Make only slight adjustments until caster fits properly.


2. Hanger hooks fit into holes inside of cabinet door.

3. Attach handle/cord holder to side of cabinet. Use screws, washers and nuts as shown on illustration.



4. Automatic drawer lock: Tool chest drawers will not open until cover is lifted up. They will also not lock in if you push them in when the cover is closed. Always lift cover, then push drawers in, and when cover is closed, they lock in place automatically.

5. There are four shelf positions inside cabinet. Choose the position height you prefer and insert the shelf at angle. Place the shelf onto assigned clips on back and side panel and push down it. Check to see if the shelf is properly placed into the clips on back and side panel.



## Parts List

For complete assembly, your Tool Chest includes the following parts:

- |   |                        |
|---|------------------------|
| 1 - Bottom Cabinet                        | 2 - M6×12 Screws       |
| 1 - Top Chest (packed inside cabinet)     | 2 - M6 Hex Nuts        |
| 1 - Cabinet Shelf (packed inside cabinet) | 2 - M6 Washers         |
| Packed in bag inside chest...             | 6 - Hanger Hooks       |
| 4 - Casters                               | 1 - Handle/Cord Holder |

