



TIPS:

Your suggestions and comments for Costway are really important to us!

We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far


February 24, 2018

Great product so far. Fast delivery, easy setup, and working without any issues.


With your inspiring rating, Costway will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!




US office:Fontana


UK office:lpswich



USER'S MANUAL
SHOPPING CART
TL35301



Wheel 4pcs 	Rear axle 1pc  Front axle 1pc 
---	---



Once the wheel is attached to axle, push the button in while gently pushing down then release the button and push up ensuring it snaps on.

To remove the wheels: simply push the button and slide wheels off.