COSTWAY



USER'S MANUAL Kids Ride On Toy TQ10053

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway











Contact Us!

Do NOT return this item-

Contact our friendly customer service department for help first.



Before You Start

Please read all instructions carefully and keep it for future reference.

Warnings:

Attention! Use it with protective equipment.

Attention! Not use it in the traffic.

Attention! The product is not suitable for the children under 3 years.

General Warnings:

- ⚠ The product must be installed and used under the supervision of an adult.
- A Read through each step carefully and follow the proper order.
- A Remove all packaging, separate and count all parts and hardware.
- ⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- \triangle We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- \triangle Ensure a secure surface during construction, und place the product always on a flat, steady and stable surface
- \triangle Please use the product carefully, as the product requires great skill, avoid accidents by the user or others, by fall or collision.
- \triangle Please wear suitable protective equipment during use, e.g. protective helmet, gloves, knee pads, elbow pads etc.

I. Product Specifications and Parameters

- 1. This product is suitable for the children of 2-6 years old, and shall be used under adult supervision!
- 2. Product dimensions: 23.7" x 12.4" x 10.3"
- 3. Product maximum load weight: 51 LBS.
- 4. Product operating ambient temperature: 32°F-104°F

II. Function and Operation

1 Function of suitcase








As shown in Fig. (a), pull out the handle; as shown in Fig. (b) and (c), it can be used as a suitcase, a good partner for family travel.

2. Function of storage case




As shown in Fig. (A), press the grid by the right hand and pull the cover upwards to open the suitcase.



As shown in Fig. **3**, open the storage case to hold children's toys and clothes in order to cultivate their ability of organization and storage.


3. Function of sleigh







As shown in Fig. (a), push two buttons towards the arrow direction, open the handle holding cover and then take the handle out. As shown in Fig. (b) and (c), it can be used as a sleigh. (When it is not used, open the handle holding cover and collect the handle according to the method shown in Fig. (b) and (c).)



As shown in Fig. ①, children can sit on the sleigh, hold the handle by both hands, and then use their feet to push back, so that it can slide freely.

III. Care and Maintenance

- 1) Regularly wipe and clean it with a piece of cloth.
- 2) The rotating parts of the car should be checked regularly to determine whether any foreign matter obstructs the rotation and to keep lubricating state of normal operation.

IV. WARNING

- 1. This product must be thoroughly checked for safety before allowing a child to use it.
- 2. It is recommended that children always wear shoes and other protective clothing and equipment (e.g. helmet, gloves, kneepads etc.) during use.
- This product must only be used on a flat level surface. Do not use it on a public road or near dangerous areas such as steps, uneven ground, water etc.
- 4. This car must only be used by a single child, maximum load 51 LBS.
- 5. Improper use may damage components.
- The product packaging is not a toy and must be kept away from children. To avoid suffocation, remove all packaging material after product assembly.
- 7. These instructions contain important information, please retain them for future reference.

↑ WARNING

To reduce the risk of injury, adult supervision is required at all times. In the interests of safety, DO NOT use this product on public roads, near motor vehicles, uneven ground, swimming pools or where there is water. Product must only be used by one child at a time.


↑ WARNING

Protective clothing and equipment should always be worn when using this product.

⚠ WARNING

Please keep the product and all parts away from children before full assembly has been completed by a responsible adult. Unassembled product contains small parts and potentially harmful sharp edges.

V. Dimensions of entire car



"Mercedes-Benz", and the design of the enclosed product are subject to intellectual property protection owned by Daimler AG. They are used by Dongguan Chi Lok Bo Toys Company Limited under license.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.





