



THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better! Contact our friendly customer service department for help first.

Follow Costway Visit us: www.costway.com

TY576038



Foldable Outdoor Cart

Replacements for missing or damaged parts will be shipped ASAP!

COSTWAY www.costway.com

Do NOT return this item.

Contact Us!

Contact our friendly customer service department for help first.



Before You Start

- Please read all instructions carefully.
- Retain instructions for future reference.
- Seperate and count all parts and hardware.
- Read through each step carefully and follow the proper order.
- We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- © Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

COSTWAY

www.costway.com

Product Specifications	
Net Weight	26 lbs
The Wheel Size	6.6x3.9 in
Pull Rod Length	23.4-38 in
Material	Polyester, PU, PP, Steel
Tires Material	PU

Thank you for choosing **GOPLUS**.

This product is suitable for camping, BBQ party, grocery shopping, having a picnic or other occasions. Please read the manual thoroughly and keep it for future reference.

Warning

- 1. Take care when assembling/disassembling the product so as to avoid finger pinch accidents.
- 2. For safety concerns, only allow children to use this product under the supervision of adults.
- 3. This wagon holds a maximum load of 110 lbs (50 kg). Exceeding maximum load capacity may cause damage to the product.
- 4. Do not use it in an extremely wet or high-temperature environment in order to extend its service life.

www.costway.com

Package Contents Instructions x1 reticule x1 cardboard x1 body x1

How To Set Up

Take out the wagon Fully extend the wagon frame. Secure the cloth of the wagon to the frame using loop enclosure



How To Fold Down

- 1. Pull up the webbing loop located at the center of the wagon.
- 2. Squeeze the wagon together and secure the wagon in a closed position

www.costway.com

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019 Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you **EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!**

US office: Fontana, California **UK office: Ipswich**



- * Reward Points
- * Exclusive Customer Service * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



- 5 -----

We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

