



Foosball Table
TY580400

USA office: Fontana

GBR office: Ipswich

AUS office: Truganina

If you're having difficulty, our friendly
customer team is always here to help.



USA:cs.us@costway.com
AUS:cs.au@costway.com
GBR:cs.uk@costway.com

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

Please read all instructions carefully and keep it for future reference.

Warning

Attention: Children should use this product under the parental supervision.

Danger: Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.



WARNING: CHOKING HAZARD


-Small parts.
Not for children under 3 years.

General Warnings

- ⚠ The product must be installed and used under the supervision of an adult.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ Remove all packaging, separate and count all parts and hardware.
- ⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- ⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.


P1	2x		P7	4x		T3	1x	
P2	2x		P8	8x		T4	1x	
P3	1x		P9	4x		S1	1x	
P4	2x		P10	2x		S2	8x	
P5	4x		T1	1x		S3	4x	
P6	2x		T2	1x		S4	4x	

1




Insert the ball box into the card slot, align the screw holes, and then fix it with screws.

2



Align the hole of the scorer to the end plate and then press the scorer fasteners to secure it in place.


3




First align one side plate with the holes on the two end plates, use screws to fix. Do not fully tighten until the last step is completed.

4

Align the sports field board with the slot of the end plate on both sides until it snaps into the slots on the side board.




5




Load buffers at both ends of the player-teams.

6




Pass teams of the same uniform through the side plate holes at an interval as shown in the figure.

7




Install teams of the same uniform in the remaining holes on the side panels as shown in the figure.

8




Pass the other side plate through the holes of the four teams, align the side plate screw holes with the holes on the end plates, and then lock the screws.

9



Install the handles and safety end caps at both ends of the teams, as shown in the figure. After pressing in place, lock the handles with screws.

10



After confirming that the installation is correct, tighten the screws to ensure that they are stable and durable.



Return / Damage Claim Instructions

- ⚠ **DO NOT discard the box / original packaging.**
In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
- ⚠ **Take a photo of the box markings.**
A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
- ⚠ **Take a photo of the damaged part (if applicable).**
A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
- ⚠ **Send us an email with the images requested.**
Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.