



www.costway.com

Baby Playpen with Safety Lock TY590329/TY590328/TY590327/TY590326/TY590325/TY590324

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com













Contact Us!

Do NOT return this item.


Contact our friendly customer service department for help first.



Before You Start

| Λ | Please | read | all | instructions | carefully | , |
|-----------|---------|------|-----|-----------------|-----------|----|
| /!\ | 1 10030 | Teau | an | 111311 46110113 | Carcium | у. |





 Δ Read through each step carefully and follow the proper order.

We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

Always place the product on a flat, steady and stable surface.

⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Warning

- 1. Users and guardians should read this package information and instructions carefully before use, and assemble the product correctly according to the instructions. If some parts are not properly installed, it may be dangerous.
- 2.Product should be assembled by adults only.
- 3. The product must be placed on a flat floor to play.
- 4. Product is only for family and indoor use.
- 5.Use it when the locking mechanism is locked.
- 6.Open plastic bag before use. Do destroy the plastic bag or keep it away from children to avoid the risk of suffocation.

Warning

- 1.Do not leave anything that may be used as a stepping point or cause suffocation or strangulation in the playpen;
- 2.Avoid fire and other strong heat sources, such as sparks, gas flames, etc. around the playpen;
- 3.Do not use the product if any part of the playpen is damaged, torn or missing;
- 4. When the child begin to stand on his or hers hands or knees, entanglement or strangulation may occur if the toy is not removed;
- 5.Do not leave children unattended when playing in the playpen;
- 6. This product is suitable for children under 44lbs;
- 7. Never use this product when a child is able to climb over it or his height is over 3.3ft.
- 8. Failure to follow these warnings and instructions may result in serious injury;

Care and Maintenance

- 1. Wipe the dirt off the surface with a dry or damp cloth.
- 2.Regularly check whether the components are assembled firmly; Keep periodic inspection of the flexibility of each rotating component; Toy may fall over or be in danger if not checked.
- 3.It is very important to operate as follows during regularly use or at the beginning of each season: Check whether all bolts and nuts are tight. If necessary, tighten them;
- Check the sharp edges of all bolts. Replace them if necessary;
- When the product is shaken or has a strong friction sound, check if all bolts and nuts are tighten and replace them if necessary;
- Please save the instruction for future reference.

Battery Safety Instructions

- 1. Remove and place the battery in the correct way;
- 2. Do not charge the non-rechargeable batteries;
- 3. Do not use different types of batteries or mix old and new batteries;
- 4. Use the same model batteries or equivalent recommended model;
- 5. Place batteries in the correct polarity;
- 6. Remove the battery from the toy when it is exhausted:
- 7. No short circuit at the power terminal;
- 8. Battery type: 2 pieces of 1.5V AAA non-rechargeable batteries.

Baby Playpen with Safety Lock Installation and Instructions For age: 6months-36 months















Pictures for reference only, subject to our available products.



| | TY590329 | х6 | | | | |
|-------------|----------|-------|---------------|---------------|------------|----------|
| | TY590328 | x8 | | | | |
| | TY590327 | x10 | | | | ® |
| Nonskid | TY590326 | x12 | × | 4 x1 | x1 | x1 |
| Flat | TY590325 | x14 | Nonskid Right | Music Box | Basketball | Knob |
| Buckle | TY590324 | x16 | angled Buckle | WIUSIC BOX | Ноор | KIIOD |
| | | | | | TY590329 | x8 |
| 1 | MOU | \ | | | TY590328 | x10 |
| [[] | | , ξ | | | TY590327 | x12 |
| ` | | , , | | | TY590326 | x14 |
| | | 'x1 | x1 | Small Playpen | TY590325 | x16 |
| Safety Gate | | Big | Playpen Panel | Panel | TY590324 | x18 |


Installation & Instruction




1.Music box installation: Align the music box to the hole in the big playpen panel and press it down.


Battery installation: Unscrew the screw on the back of the music box, open the battery box and insert the battery according to different polarity.

Use 2 pieces of 1.5V AAA non-rechargeable batteries. (Not included)







2.Connect the playpen panel: As shown in the figure, press one pillar at the hole of the other pillar. The subsequent operations are the same. (Install small playpen panels according to the actual quantity)



3.Non-skid buckle and nonskid right-angled buckle assembly: As shown in the figure, align the nonskid flat buckle to connection joint of the playpen and tighten it. Install the nonskid right-angled buckle at the corner, the same operations as above. (Install nonskid flat buckles according to the actual quantity)



4.Basketball hoop installation: As shown in the figure, put the basketball hoop through the hole in the safety gate and tighten it with the knob.



5.Check: After completing the installation according to the above steps, check whether each buckle is installed in right place.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

