

COSTWAY®



USER'S MANUAL





2 SET Swivel Stool





HW61764/HW61765

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

-  Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
-  Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
-  Work in a spacious area, preferably on a carpet close to where the unit will be used.
-  Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



Part List

A



Backrest x 2

B




Chair Leg x 8

C



Footrest x 2

D



Apron x 2

E



Cushion with Apron x 2

Hardware List



M6 x 25mm

①

x 8

JCBC Screw



M6 x 40mm

②

x 20

JCBC Screw



M6 x 13mm

③

x 28

Spring Washer



M6 x 16.5mm

④

x 28

Flat Washer



M4 x 110mm

⑤

x 1

Allen Key




M6 x 35mm

⑥

x 8


JCBC Screw

STEP 1




Attach each leg (B) to footrest (C). Insert each individual set of hardware as per picture shown. Do not tight up any hardware completely.


STEP 2



Attach each leg (B) to apron (D). Insert each individual hardware as per picture shown. Tight up 4 legs with apron first, then tight up footrest with 4 legs completely.

STEP 3

Insert 6 sets hardware first, then tight up part (A) with part (E) together after alignment is done.

STEP 4



COMPLETED ASSEMBLY

x 2

Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment.

Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.



Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich AU office: Truganina



Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US:cs.us@costway.com
UK:cs.uk@costway.com
AU:cs.au@costway.com